

15W Filterless Stereo Class D Audio Amplifier

General Description

The VA2213 is a cost-effective filter-less Class D stereo audio power amplifier that operates in wide range of various power supplies. VA2213 provide volume control with four selectable gain settings (20dB, 26dB, 32dB, 36dB). VA2213 can output 15W per channel into 8Ω load with lower supply current and fewer external components for driving bridged-tied stereo speaker directly. With the function of power limit, the speakers could be operated safely and the input signal would be also normalized.

VA2213 operates with high efficiency energy conversion up to 88% (8 Ω Load) so that the external heat sink can be eliminated while playing music.

VA2213 also integrates Anti-Pop, Output Short & Over-Heat Protection Circuitry to ensure device reliability. This device also provides the DC detect Applications and protection scheme to prevent the damage of speaker voice coils.

The VA2213 is available in small TSSOP-28 green package with exposed pad.

Features

- Operation Voltage from 8V to 26V
- Maximum 88% Efficiency with an 8Ω Speaker
- 16.5W@8 Ω Load with THD+N =1% at 18V
- 12.2W@4 Ω Load with THD+N =1% at 12V
- 14.9W@4 Ω Load with THD+N =10% at 12V
- $9.3W@8\Omega$ Load with THD+N =10% at 12V
- Mute Control For Less CODEC Pop-up Noise
- Four Selectable Gain Settings
- Scalable Power Limit Function
- Speaker DC Detection and Protection
- Parallel BTL Speaker Driving Connection
- Thermal Protection with Auto-Recovery
- Speaker Protection Circuitry
- Short Circuit and Thermal Protection
- RoHS 2.0 compliant TSSOP-28 Green Package with Exposed Pad

- LCD TV
- **Multimedia Speakers**
- Sound Bar



Typical Application





Functional Block Diagram





Pin Assignments And Descriptions



Pin No.	Pin	I/O/P	Function Description	
1	SD_B		Shutdown control terminal. Low active. TTL Logic levels with compli-	
1	3D_B		ance to AVDD.	
2	FAULT_B	0	Protection Flag Indicator (Open Drain). Connecting FAULT_B and SD_B	
2	FAULT_D	0	can be set to auto-recovery. Otherwise need to reset by cycling AVDD.	
3	LINP	I	Left channel positive audio signal input.	
4	LINN	I	Left channel negative audio signal input.	
5	GAIN0	I	Gain selection least significant bit.	
6	GAIN1	I	Gain selection most significant bit.	
7	AVDD	Р	Analog Power Supply.	
8	AGND	Р	Analog Ground.	
9	VREG	0	Regulated Voltage. Nominal voltage is 5.5V.	
10	PLIMIT	1	Power Limit Level Adjust. Connect a resistor divider from VREG to GND	
10	P LIMIT	I	to set power limit. Connect to VREG directly for no power limit.	
11	RINN	I	Right channel negative audio signal input.	
12	RINP	I	Right channel positive audio signal input.	
13	13 MUTE I		Mute signal for fast disable/enable of outputs (HIGH = outputs Hi-Z,	
51	MOTE		LOW = outputs enabled). TTL logic levels with compliance to AVDD.	
14	PBTL	I	Parallel BTL mode switch.	
15,16	PVDDR	Р	Right channel power supply.	
17	BSPR	I	Bootstrap I/O for right channel positive high-side switch.	
18	ROUTP	0	Right channel positive output.	
19	PVSSR	Р	Right channel power ground.	
20	ROUTN	0	Right channel negative output.	
21	BSNR	I	Bootstrap I/O for right channel negative high-side switch.	
22	BSNL	I	Bootstrap I/O for left channel negative high-side switch.	
23	LOUTN	0	Left channel negative output.	
24	PVSSL	Р	Left channel power ground.	
25	LOUTP	0	_eft channel positive output.	
26	BSPL	0	Bootstrap I/O for left channel positive high-side switch.	
27,28	PVDDL	Р	Left channel power supply.	



Absolutely Maximum Ratings

Over operating free-air temperature range, unless otherwise specified (* 1)

Symbol	Parameter	Limit	Unit
V _{DD} (PVDDR, PVDDL, AVDD)	Supply voltage	-0.3 to 30	V
V _I (GAINO, GAIN1, PBTL, FALUT_B, MUTE, SD_B)	Input voltage	-0.3 to $V_{\text{DD}}{+}0.3$	V
V _I (PLIMIT)	Input voltage	–0.3 to $V_{\text{REG}} {+} 0.3$	V
V _I (LINN, RINN, LINP, RINP)	Input voltage	-0.3 to 6.5	V
T _A	Operating free-air temperature range	-40 ~ +85	۰C
Tj	Operating junction temperature range(* 2)	-40 to +150	۰C
T _{STG}	Storage temperature range	-65 to 150	۰C
R _(LOAD)	Minimum load resistance	8 (V _{DD} >15V) 4 (V _{DD} ≤15V)	Ω
θ _{JC}	Thermal Resistance (Junction to Case)	8	°C/W
θ _{JA}	Thermal Resistance (Junction to Air)	45	°C/W
Electrostatic discharge	Human body model	±2	kV
Electrostatic discharge	Machine model	±200	V

(*1): Stress beyond those listed at "absolute maximum rating" table may cause permanent damage to the device. These are stress rating ONLY. For functional operation are strongly recommend follow up "recommended operation conditions" table.

Recommended Operating Conditions

Over operating free-air temperature range, unless otherwise specified.

Symbol	Parameter	Test Condition	Specif	Unit	
Symbol	rarameter		Min	Max	onne
V_{DD}	Supply voltage	PVDDL, PVDDR, AVDD	8	26	V
	High level input voltage				
VIH	(GAIN0, GAIN1, PBTL, MUTE,	$V_{DD}=24V$	2		V
	SD_B)				
	Low level input voltage				
VIL	(GAIN0, GAIN1, PBTL, MUTE,	$V_{DD}=24V$		0.8	V
	SD_B)				
V _{OL}	Low level output voltage (FAULT_B)	V_{DD} =24V, $R_{PULL-HIGH}$ =100k Ω		0.8	V
T _A	Operating free-air temperature		-40	85	۰C



Electrical Characteristics

 $T_{A}=25^{\circ}\!C,\,V_{DD}=12V,\,R_{L}{=}8\Omega,\,GAIN{=}20dB,\,unless$ otherwise noted.

Symbol	Parameter	Test Condition		Specification			Unit
Symbol	ratameter	Test Con	lution	Min	Тур.	Max	onic
V _{os}	Output offset voltage (measured differentially)	V _I =0	V _I =0V		1.5	15	mV
Ι _Q	Quiescent current	SD_B=2V, No lo	oad, w/o L/C		25	40	mA
I _{SD}	Shutdown current	SD_B=0.4V	, No load		300	450	μA
t _{on}	Shutdown turn-on time	SD_B=	=2V		20		ms
t _{OFF}	Shutdown turn-off time	SD_B=0.8V			2		μs
f _{osc}	Internal oscillation frequency				260		kHz
		GAIN1=0.8V, 0	GAIN0=0.8V		20		
А	Amplifier gain	GAIN1=0.8V, GAIN0=2V			26		dB
A	Ampiner gam	GAIN1=2V, GAIN0=0.8V			32		UB
		GAIN1=2V, 0	GAIN0=2V		36		
P	Drain-Source ON resistance ¹	$V_{DD}=12V$,	High Side		240		mΩ
R _{DS(ON)}		$I_{OUT}=500 mA$	Low Side		240		11122
V _{REG}	Regulator output	$I_{VREG} = 100 \mu A, V_{DD} = 8 \sim 25 V$		5.25	5.5	5.75	V
t _{DC-DET}	DC detect time				450		ms

(1) Design center value.

Electrical Characteristics

 $T_{A}=25^{\circ}\!C,\,V_{DD}=24V,\,R_{L}{=}8\Omega,\,GAIN{=}20dB,\,unless$ otherwise noted.

Symbol	Parameter	Test Condition		Specification			Unit
Symbol	Symbol Falameter		union	Min	Тур.	Max	Unit
V _{os}	Output offset voltage (measured differentially)	V _I =0V			1.5	15	mV
Ι _Q	Quiescent current	SD_B=2V, No lo	oad, w/o L/C		35	50	mA
I _{SD}	Shutdown current	SD_B=0.4V	, No load		350	500	μA
t _{on}	Shutdown turn-on time	SD_B=	=2V		20		ms
t _{OFF}	Shutdown turn-off time	SD_B=0.8V			2		μs
f _{osc}	Internal oscillation frequency				260		kHz
		GAIN1=0.8V, 0	SAIN0=0.8V		20		
А	Amplifier gain	GAIN1=0.8V, GAIN0=2V			26		dB
A	Ampimer gam	GAIN1=2V, GAIN0=0.8V			32		ив
		GAIN1=2V, 0	GAIN0=2V		36		
D	Drain-Source ON resistance ¹	$V_{DD}=12V$,	High Side		240		mΩ
R _{DS(ON)}		$I_{OUT} = 500 mA$	Low Side		240		11122
V _{REG}	Regulator output	$I_{VREG} = 100 \mu A, V_{DD} = 8 \sim 25 V$		5.25	5.5	5.75	V
t _{DC-DET}	DC detect time				450		ms

(1) Design center value.



Operating Characteristics

$V_{DD}=12V, A_{V}=20dB, T_{A}=$	25℃ unless	otherwise noted.
$v_{DD} - i z v, Av - z o a D, i A - $	2 J C unics J	otherwise noted.

Symbol	Parameter	Test Condition		Test Condition Specification		on	Unit
Symbol	Parameter			Min	Тур.	Мах	Unit
Po	Output power	THD+N=10%, f=1kHz	, $R_L=8\Omega$, $V_{DD}=13V$		10		W
THD+N	Total harmonic dis- tortion plus noise	$V_{DD} = 12V, P_0 = 5W, R_L = 3$	8Ω, f=1kHz		0.07		%
K _{svr}	Supply ripple rejec- tion ration	Input AC-Grounded, $C_i=1\mu F$, f=1kHz			70		dB
SNR	Signal-to-Noise ratio	A-weighted, THD+N=1%, $R_L=8\Omega$			97		dB
Vn	Output voltage noise	•	No Weight		100		μV _{RMS}
		Grounded, C _i =1µF	A–Weighted		80		
CMRR	Common mode re- jection ratio	$V_{DD}=12V$, $V_{IC}=1V_{PP}$ f=120Hz			66		dB
Crosstalk	Channel separation	V ₀ =1W, f=1kHz, Gain	=20dB		102		dB

Operating Characteristics

 $V_{\text{DD}}{=}24V,\,A_{v}{=}20dB,\,T_{A}=25\,^{\circ}\!\!\mathrm{C}$ unless otherwise noted.

Symbol Parameter		Test Condition		Specification			Unit
		Test Cond	Test condition		Тур.	Мах	Unit
Po	Output power	THD+N=10%, f=1kHz	, $R_L=8\Omega$, $V_{DD}=16V$		15		W
THD+N	Total harmonic dis- tortion plus noise	V_{DD} =24V, P_{O} =10W, R_{L} =	=8Ω, f=1kHz		0.08		%
$ \mathbf{K}_{SVR} $	Supply ripple rejec- tion ration	Input AC-Grounded, C		68		dB	
SNR	Signal-to-Noise ratio	A-weighted, THD+N=1%, $R_L=8\Omega$			99		dB
Vn	Output voltage noise		No Weight		100		μV _{RMS}
		Grounded, $C_i = 1 \mu F$	A–Weighted		80		
CMRR	Common mode re- jection ratio	$V_{DD} = 12V, V_{IC} = 1V_{PP}$ f=120Hz			66		dB
Crosstalk	Channel separation	Vo=1W, f=1kHz, Gain	=20dB		101		dB



Functional Descriptions

Gain Settings

The gain of the VA2213 can be set by GAIN0 and GAIN1 pins. The gain ratios listed in Table 1 are implemented by changing the taps on the feedback resistors in the preamplifier stage.

The input resistance is depended on the gain setting. Since the gain setting is determined by the ratio of the internal feedback resistive network, the variation of the gain is small. But the absolute value of the input resistance may shift by $\pm 20\%$ at the same gain. In actual design cases, 80% of nominal value should be assumed as the input resistance of VA2213 in the input network of whole amplifier.

Gain 1	Gain 0	Gain Ratio	Resistance	Range
1	1	36dB	9kΩ	7.2kΩ~10.8kΩ
1	0	32dB	15kΩ	12kΩ~18kΩ
0	1	26dB	30kΩ	24kΩ~36kΩ
0	0	20dB	60kΩ	48kΩ~72kΩ



Amplifier Input Impedance



Figure 1. Cut-off Point of High-pass Filter

In most cases, no extra resistor needs to be added on the input of VA2213. The actual input resistor is already determined while selecting the gain. If a single capacitor is used in the input high-pass filter, the cut-off frequency fo may vary with the change of gain setting. The -3dB point of the cut-off frequency can be calculated by the following equation,

$$fo = \frac{1}{2\pi \times R_1 \times C_1} \qquad (Hz) \quad Equation (2)$$

,where the R_1 values is given in Table 1.

Shutdown Operation

The VA2213 employs a state of shutdown mode to reduce supply current to the absolute minimum level during periods of nonuse for power conservation. This terminal should be held high during normal operation when the amplifier is in normal operating. Pulling low causes the output drivers shutdown and the amplifier to enter a low-current state. Do not leave it unconnected, because there is no weakly pulling resistor inside the amplifier.

Remember that to place the amplifier in the shutdown state prior to removing the power supply voltage so that power-off pop noise can be eliminated.

VREG Supply

The V_{REG} Supply is used to bias the gates of the output full-bridge upper half MOSFETs. It could be used to supply the PLIMIT pin and related voltage divider circuit. Add at least 1µF capacitor to ground at this pin.

Speaker Protection

Due to the nature of Class D amplifiers, the speakers may have DC current if the audio inputs get DC voltage in any case. An output DC fault will make FAULT_B pin in low state and shuts down the audio amplifier and change the state of output into



Functional Descriptions (cont.)

high impedance.

ground.

To resolve the case of DC input, it is good to treat it as very low frequency sine wave much lower than audio band such as 2Hz. Based on this criteria, a DC detect fault shall be issued when the output differential duty-cycle of either channel exceeds 14% T for more than 500ms at the same polarity. This feature protects the speakers away from large currents.

The minimum differential input DC voltages required to trigger the DC detection fault are listed in Table 2.

A _v (dB)	V _{IN} (mV, Differential)
36	17
32	28
26	56
20	112

Table 2. DC detect fault threshold

To resume the normal operation, it is necessary to power off the amplifier and then power on, cycling SD_B can not resume normal operation.

Parallel BTL Mode for Mono Operation

VA2213 offers the feature of Stereo operation with two outputs of each channel connected directly. If the PBTL pin (pin 14) is tied high, the positive and negative outputs of each channel (left and right) are synchronized and in phase. To operate in this mono mode, apply the input signal to the RIGHT input and place the speaker between the LEFT and RIGHT outputs. Connect the positive and negative output together for best efficiency. Parallel BTL mode can increase more output power compare to the stereo mode single channel's output power. For normal BTL operation, connect the PBTL pin to Short Circuit Protection

VA2213 has protection from over-current conditions caused by a short circuit on the output stage. The short circuit protection fault is reported on the FAULT_B pin as a low state. The amplifier outputs are switched to a high impedance state when the short circuit protection latch is engaged. The latch can be cleared by cycling the SD_B pin through the low state.

Connect FAULT_B to SD_B pin, the over current protection will be auto recovery.

Thermal Protection

Thermal protection on the VA2213 prevents damage to the device when the internal die temperature exceeds 160°C. There is a ± 20 °C tolerance on this trip point from device to device. Once the die temperature exceeds the thermal set point, the device enters into the shutdown state and the outputs are disabled. This is not a latched fault. The thermal fault is cleared once the temperature of the die is reduced by 50°C. VA2213 will be back to normal operation at this point with no external system interaction.

Thermal protection fault will not be reported on the FAULT_B terminal.

Power Limit Operation

The voltage at PLIMIT terminal (pin 10) can be used to limit the power to levels below that which is possible based on the supply rail. Add a resistor divider from VREG to ground to set the voltage at the PLIMIT terminal. An external reference may also be used if precise limitation is required. Also add a



Functional Descriptions (cont.)

 $1\mu F$ capacitor from this pin to ground.

The PLIMIT circuit sets a limit on the output peak-to -peak voltage. The limiting is done by limiting the duty cycle to fixed maximum value. This limit can be thought of as a "virtual" voltage rail which is lower than the supply connected to power rail. This "virtual" rail is about 5.2 times the voltage at the PLIMIT pin. This output voltage can be used to calculate the maximum output power for a given maximum input voltage and speaker impedance.

$$P_{OUT} = \frac{\left(\left(\frac{R_L}{R_L + 2 \times R_s}\right) \times V_P\right)^2}{2 \times R_L}$$

where R_s is the total series resistance including $_{RDS}$ $_{(ON)}$ and any resistance in the output filter. R_L is the load resistance. V_P is the peak amplifier of the output possible within the supply rail.

N 00			Po@THD+N (W)		
V _{DD} (V)	R _L (Ω)	PLIMIT(V)	10%	1%	
12	8	0.93	1.328	1.005	
12	8	1.107	1.923	1.452	
12	8	1.33	2.955	2.118	
12	8	1.434	3.527	2.536	
24 (Heat Sink)	8	1.612	3.746	2.994	
24 (Heat Sink)	8	1.899	5.267	3.999	
24 (Heat Sink)	8	2.238	7.069	5.677	
24 (Heat Sink)	8	2.683	10.77	8.299	
12	4	0.89	1.972	1.518	
12	4	1.117	3.123	2.406	
12	4	1.285	4.144	3.175	
12	4	1.408	5.007	3.839	

Table 3. PLIMIT value vs. Output Power

Due to the VREG driving ability limitation, it is not recommended to use this pin to drive other circuits except PLIMIT resistor network. The recommended resistor network is shown on Figure 2.



Figure 2. PLIMIT Pin Voltage Divider Use the simple voltage divider to determine the voltage on PLIMIT pin from VREG pin by the following equation:

$$V_{PLIMIT} = V_{VREG} \frac{10 k\Omega}{10 k\Omega + R_{LIMIT}}$$

In order to maintain the regulation of VREG pin well please apply higher resistor value such as $10k\Omega$ on low side resistor but should not exceed $50k\Omega$.

Mute Operation

The MUTE pin is an input for controlling the output state of the VA2213. A logic high on this terminal disables the outputs. A logic low on this pin enables the outputs. This terminal may be used as a quick disable/enable of outputs when transitioning between different audio sources, or turning off output stage to eliminate the charging noise from upstream CODEC capacitor. The MUTE terminal is recommended not to be left floating. For power conservation, the SD_B terminal should be used to reduce the quiescent current to the absolute minimum level.



Application Information

Output Filter

Design the VA2213 without the filter if the traces from amplifier to speaker are short (< 10cm), where the speaker is in the same enclosure as the amplifier is a typical application for class D without a filter. Many applications require a ferrite bead filter at least. The ferrite filter reduces EMI above 30MHz. When selecting a ferrite bead, choose one with high impedance at high frequencies, but low impedance at low frequencies, be aware of its maximum current limitation.

Use an LC output filter if there are low frequency (<1 MHz) EMI sensitive circuits and there are long wires from the amplifier to the speaker.



Figure 3. Typical LC Output Filter, Speaker Impedance= 8Ω



Figure 4. Typical LC Output Filter, Speaker Imped ance=4 Ω



Figure 5. Typical Ferrite Chip Bead Output Filter, Speaker Impedance= 8Ω

Inductors used in LC filters must be selected carefully. A significant change in inductance at the peak output current of the VA2213 will cause increased distortion. The change of inductance at currents up to the peak output current must be less than 0.1μ H per amp to avoid this. Also note that smaller inductors than 33μ H may cause an increase in distortion above what is shown in preceding graphs of THD versus frequency and output power.

Like the selection of the inductor in LC filters, the capacitor must be selected carefully, too. A significant change in capacitance at the peak output voltage of the VA2213 will cause increased distortion. LC filter capacitors should be double of DC voltage ratings of the peak application voltage (the power supply voltage) at least. In general, it is strongly recommended using capacitors with good temperature performance like X5R series.

Output Snubbers

In Figure 6, the 330pF capacitors in series with 10Ω resistors connected with the outputs of the VA2213 are snubber circuits. They smooth switching transitions and reduce overshoot and ringing. With these networks, THD+N can be improved at lower power levels and EMC can be reduced 2~4 dB at middle frequencies. They increase quiescent current by 3mA~11mA depends on supply voltage.



Application Information (cont.)



Figure 6. Output Snubber Circuits

Low ESR Capacitors

Low ESR capacitors are high recommended for this application. In general, a practical capacitor can be modeled simply as a resistor in series with an ideal capacitor. The voltage drop across this unwanted resistor can eliminate the effects of the ideal capacitor. Place low ESR capacitors on supply circuitry can improve THD+N performance.

Boot-Strap Capacitors

The full H-bridge output stages use only MOS transistors. Therefore, they require bootstrap capacitors for the high side of each output to turn on correctly. A 0.22μ F ceramic capacitor, rated for at least 25V, must be connected from each output to its corresponding boot-strap input. Specifically, one 0.22μ F capacitor must be connected from OUTP to BSP, and one 0.22μ F capacitor must be connected from OUTN to BSN.

The bootstrap capacitors connected between the BSP or BSN pins and corresponding output function as a floating power supply for the high side N-channel power MOSFET gate drive circuitry. During each high side switching cycle, the bootstrap capacitors hold the gate-to-source voltage high enough to keep the high-side MOSFETs turned on.

Decoupling Capacitors

VA2213 requires appropriate power decoupling to minimize the output total harmonic distortion (THD) and improves EMC performance. Power supply decoupling also prevents intrinsic oscillations for long lead lengths between the amplifier and the speaker. The optimum decoupling can be achieved by using two different types of capacitors which target different types of noise on the power supply lines. For higher frequency spikes, or digital hash on the rail, a good low ESR ceramic capacitor, for example $0.1\mu F$ to $10\mu F$, placed as close as possible to PVDDR and PVDDL pins works best. For filtering lower frequency noise, a larger low ESR aluminum electrolytic capacitor of 470µF or greater placed near the audio power amplifier is suggested. The 470µF capacitor also serves as local storage capacitor for supplying current during heavy power output on the amplifier outputs. The PVDDR and PVDDL terminals provide the power to the output transistors, so a $470 \mu F$ or larger capacitor should be placed by PVDDR and PVDDL terminals as near as possible. A 10µF ceramic capacitor on each PVDDR/PVDDL terminal is also recommended.

PCB Layout Guidelines

The VA2213 can be used with a small, inexpensive ferrite bead output filter for most applications. However, since the Class-D amplifier switching edges are fast, it is necessary to take care when planning the layout of the printed circuit board. The following guidelines will help to increase EMI/ EMC compatibility.

 The high frequency decoupling capacitors should be placed as close to the PVDDL/ PVDDR and AVDD terminals as possible. Large (100µF or greater) bulk power supply decoupling capacitors should be placed near the



Application Information (cont.)

VA2213 on the PVDDL and PVDDR supplies. Place high-frequency bypass capacitors (such as 1µF MLCC type) should be placed as close to the VREG pin as possible to increase stability. These capacitors can be connected to the thermal pad directly for an excellent ground connection. Consider adding some small, good quality low ESR ceramic capacitors between 1nF and 10nF and larger mid-frequency capacitors of value between 0.1µF and 1µF also of good quality to the PVDDL and PVDDR connections at each end of the chip.

- 2. Keep the current loop from each of the outputs through the ferrite bead and the small filter capacitor and back to PVSSL/PVSSR as small and tight as possible. The area of this current loop determines its effectiveness as an antenna.
- Grounding. The AVDD (pin 7) decoupling ca-3. pacitor should be grounded to analog ground (AGND). The PVDDL/PVDDR decoupling capacitors should connect to PVSSL/PVSSR. Analog ground and power ground should be connected at the thermal pad. The VA2213 is a high-performance CMOS audio amplifier that requires adequate power supply decoupling to ensure the output total harmonic distortion (THD) is as low as possible. Power supply decoupling also prevents the oscillations being caused by long lead length between the amplifier and the speaker. The optimum decoupling is achieved by using two different types of capacitors that target on different types of noise on the power supply leads. For higher frequency transients, spikes, or digital hash on the line, a good low equivalentseries-resistance (ESR) ceramic capacitor, typically 1µF placed as close as possible to the device AVDD pin, ground connection or star ground for the VA2213.
- 4. Output Filter. The ferrite EMI filter (Figure 5)

should be placed as close to the output terminals as possible for the best EMI performance. The LC filter (Figure 3 and 4) should be placed close to the outputs. The capacitors used in both the ferrite and LC filters should be grounded to power ground.





Typical Characteristic

Test Setup Connection Diagram



* Remove all L/C (BEAD) filter components on board before performing all measurements.

** Connection diagram is for one-channel configuration.

Figure No.	Description	Output Load
7	Frequency Response (12V)	
8	Frequency Response (24V)	
9	THD+N vs. Frequency (12V)	
10	THD+N vs. Frequency (24V)	
11	Crosstalk (12V/1W)	
12	Crosstalk (24V/1W)	8Ω
13	Noise FFT	
14	Efficiency	
15	THD+N vs. Output Power (12V)	
16	THD+N vs. Output Power (24V)	
17	PLIMIT voltage vs. Output Power (12V)	
18	Frequency Response (12V)	
19	THD+N vs. Frequency (12V)	
20	THD+N vs. Output Power (12V)	
21	Crosstalk (12V/1W)	4Ω
22	Noise FFT	
23	Efficiency	
24	PLIMIT voltage vs. Output Power	



Typical Characteristic (cont.)



Figure 7. Frequency Response



Figure 9. THD+N vs. Frequency





Figure 13. Noise FFT



Figure 8. Frequency Response



Figure 10. THD+N vs. Frequency



Figure 12. Crosstalk







Typical Characteristic (cont.)







Figure 17. PLIMIT voltage vs. Output Power



Figure 19. THD+N vs. Frequency



Figure 21. Noise FFT



Figure 16. THD+N vs. Output Power



Figure 18. Frequency Response



Figure 20. THD+N vs. Output Power









Typical Characteristic (cont.)



PLIMIT Voltage VS Output Power



Figure 24. PLIMIT voltage vs. Output Power





Application Circuit



Figure 25. VA2213 Stereo Reference Application Circuit









Package Information

TSSOP-28



∟у

NOTE

1. PACKAGE BODY SIZES EXCLUDE MOLD FLASH PROTRUSIONS OR GATE BURRS

- 2. TOLERANCE ±0.1 mm UNLESS OTHERWISE SPECIFIED
- 3. COPLANARITY : 0.1 mm
- 4. REFER TO JEDEC MO-153

SYMBOLS	DIMENSIONS IN MILLIMETER			DIMENSIONS IN INCH		
SIMBOLS	MIN	NOM	MAX	MIN	NOM	MAX
Α			1.15			0.045
A1	0.00		0.10	0.000		0.004
A2	0.80	1.00	1.05	0.031	0.039	0.041
b	0.19		0.30	0.007		0.012
С	0.09		0.20	0.004	—	0.008
D	9.60	9.70	9.80	0.378	0.382	0.386
D2	3.70	3.80	3.90	0.146	0.150	0.154
E	6.20	6.40	6.60	0.244	0.252	0.260
E1	4.30	4.40	4.50	0.169	0.173	0.177
E2	2.70	2.80	2.90	0.106	0.110	0.114
e		0.65			0.026	_
L	0.45	0.60	0.75	0.018	0.024	0.030
У			0.10			0.004
θ	0°		8°	0°		8°
🛽 L1-L1'			0.12			0.005
\land L1	1.00REF			0.039REF		



Recommended PCB Layout Land Pattern





Ordering Information



Contact Information

Viva Electronics Incorporated

10F-1, No. 32, Gaotie 2nd Rd., Zhubei City, Hsinchu County, Taiwan, R.O.C. Tel: 886-3-6579508 Fax: 886-3-6579509 WWW: <u>http://www.viva-elec.com.tw</u> Sales: <u>sales@viva-elec.com.tw</u> FAE Support: <u>fae@viva-elec.com.tw</u>

IMPORTANT NOTICE

Viva Electronics Incorporated reserves the right to make changes without further notice to any products or specifications herein. Viva Electronics Incorporated does not assume any responsibility for use of any its products for any particular purpose, nor does Viva Electronics Incorporated assume any liability arising out of the application or use of any its products or circuits. Viva Electronics Incorporated does not convey any license under its patent rights or other rights nor the rights of others.