



内置高效率自适应电荷泵升压,防削顶失真功能,D/AB切换的 5.5W单声道高保真音频功率放大器

■ 特点

- ・防削顶失真功能(Anti-Clipping Function, ACF)
- 自适应电荷泵升压功能
- ・内部固定28dB増益
- 输出功率(Class D)
 5.5W (V_{BAT}=4.2V, R_L=4Ω+22uH, THD+N=10%)
 4.5W (V_{BAT}=4.2V, R_L=4Ω+22uH, THD+N=1%)
- 输出功率(Class AB)
 2.8W (V_{BAT}=5V, R_L=4Ω, THD+N=10%)
 2.3W (V_{BAT}=5V, R_L=4Ω, THD+N=1%)
- ・电源 -升压输入V_{BAT}: 2.7V至5.5V -升压输出PVDD: 6.6V
- •静态工作电流: 3mA
- ・关断电流: <1uA
- ・AB/D类可切换
- 免滤波器数字调制,直接驱动扬声器
- ·保护功能:过流/过热/欠压异常保护功能
- ・无铅封装, SOP10L-PP

■ 应用

- 智能音响
- 便携式音频设备

・无线音响・智能手机

■ 概述

HT8313 是 一 款 D 类 音 频 功 率 放 大 器 , 在 V_{BAT}=5V、THD+N=10%, 4Ω负载条件下能连续输 出5.5W功率。该D类功放的电源电压由内置的自适 应电荷泵升压模块提供。该升压模块在低功率时不 升压,可有效提升电池的播放时间。

HT8313的最大特点是防削顶失真(ACF)输出 控制功能,可检测并抑制由于输入音乐、语音信号 幅度过大所引起的输出信号削顶失真(破音),也能 自适应地防止在升压电压下降所造成的输出削顶, 显著提高音质,创造非常舒适的听音享受,并保护 扬声器免受过载损坏。

HT8313具有AB类和D类的自由切换功能,在受到D类功放EMI干扰困扰时,可随时切换至AB类音频功放模式(此时电荷泵升压功能关闭)。

HT8313内部集成免滤波器数字调制技术,能够 直接驱动扬声器,并最大程度减小脉冲输出信号的 失真和噪音。输出无需滤波网络,极少的外部元器 件节省了系统空间和成本,是便携式应用的理想选 择。

此外,HT8313内部固定28dB增益,内置的关 断功能使待机电流最小化,还集成了输出端过流保 护、片内过温保护和电源欠压异常保护等功能。

■ 典型应用图





5.5W Anti-Clipping Mono Class D/AB Audio Amplifier with Adaptive Charge Pump Regulator

FEATURE

- Anti-Clipping Function (ACF)
- Adaptive Charge Pump Regulator
- Maximum Voltage Gain: 28dB
- · Output Power (Class D)
 - 5.5W (V_{BAT}=5V, R_L=4\Omega, THD+N=10%) 4.5W (V_{BAT}=5V, R_L=4\Omega, THD+N=1%)
- Output Power (Class AB)

2.8W (V_{BAT}=5V, R_L=4\Omega, THD+N=10%) 2.3W (V_{BAT}=5V, R_L=4\Omega, THD+N=1%)

Power Supply

-Input V_{BAT}: 2.7V to 5.5V

-Output PVDD: 6.6V

- Quiescent Current: 3mA
- Shutdown Current: <1uA
- Class AB / Class D selectable
- · Filter-less Modulation, Eliminating Output Filter
- Over Current Protection, Thermal Protection,

Low voltage malfunction prevention function included

Pb-Free Packages , SOP10L-PP

APPLICATIONS

- Smart Speakers
 Wireless Speakers
- Portable Audio Devices
 Smart Phones

TYPICAL APPLICATION

GENERAL DESCRIPTION

HT8313 is a Class D audio amplifier which can deliver continuous 5.5W output power into a 4Ω speaker with 5V power supply when THD+N = 10%. The class D audio amplifier's power supply is adaptively boosted by the integrated charge pump regulator which only works while the output power is big enough. This will significantly extend the playing time in battery supply applications.

HT8313 features Anti-Clipping Function (ACF) which detects output signal clip due to the over input signal and suppresses the output signal clip automatically. Also, it can adapt the output clip caused by power supply voltage down. It can significantly improve the sound quality, creating a very comfortable musical enjoyment, and to protect the speakers from overload damage.

Class AB amplifier mode is also available for HT8313. Once the EMI Interference from class D and Boost Converter becomes an annoying problem, HT8313 can be changed into Class AB mode.

HT8313 has a filter-less modulation circuit which directly drives speakers while realizes low distortion and low noise characteristics. Thanks to filter-less, circuit design with fewer external parts can be made in portable applications.

HT8313 has an internal gain of 28dB and an independent Shutdown function which can minimize the power consumption. As for protection function, over current protection function for speaker output terminals, over temperature protection function, and low supply voltage malfunction preventing function are also prepared.





■ TERMINAL CONFIGURATION



SPE (ESSOP10) Top View

■ TERMINAL FUNCTION¹

Terminal No.	Name	I/O	ESD Protection	Description	
0	GND	GND		Ground	
1	PVBAT	POWER	PN	Power supply for the charge pump regulator	
2	CP	I	PN	Flying capacitor positive terminal	
3	CN	I	PN	Flying capacitor negative terminal	
4	CTRL	I	PN	Mode selection terminal. When it is pulled low, the device goes into shutdown mode.	
5	AVBAT	POWER	PN	Analog power supply	
6	IN+	I	PN	Positive audio input terminal	
7	IN-	I	PN	Negative audio input terminal	
8	OUT+	0	PN	Positive BTL audio output	
9	OUT-	0	PN	Negative BTL audio output	
10	PVDD	POWER	PN	Power supply for audio amplifier	



ORDERING INFORMATION

Part Number	Package Type	Marking	Operating Temperature Range	Shipping Package / MOQ
HT8313SPET	ESSOP10 (SPE)	HT8313 YYYMAAB ²	-40 ℃ ~85 ℃	Tape and Reel (R) / 2500pcs
HT8313SPER	ESSOP10 (SPE)	НТ8313 ҮҮҮМААВ	-40 ℃ ~85 ℃	Tube (T) / 100pcs

Part Number



Production Tracking Code





• ELECTRICAL CHARACTERISTICS³

Absolute Maximum Ratings⁴

PARAMETER	SYMBOL	MIN	MAX	UNIT
Supply voltage range (PVBAT, AVBAT)	VBAT	-0.3	7	V
Input voltage range (IN+, IN-)	Vin	-0.6	AVBAT+0.6	V
Operating temperature range	TA	-40	85	°C
Operating junction temperature range	TJ	-40	150	°C
Storage temperature range	Tstg	-50	150	°C

• Recommended Operating Conditions

PARAMETER	SYMBOL	CONDITION	MIN	TYP	MAX	UNIT
Supply voltage range (PVBAT, AVBAT)	VBAT		2.7	2.7	5.5	V
Operating temperature range	Ta		-40	25	85	°C
Speaker resistance	R∟			4		Ω

• Electrical Specifications

General Specifications

Condition: VBAT = 2.7~5.5V, $T_A = 25^{\circ}$ C, Unless otherwise specified.

PARAMETER	SYMBOL	CONDITION	MIN	TYP	MAX	UNIT
Supply voltage range (PVBAT, AVBAT)	VBAT		2.7	3.7	5.5	V
Power-up threshold voltage	Vuvlh			2.7		V
Power-off threshold voltage	Vuvll				2.5	V
Quipagent ourrent	I	3.6V, No input, No load, Class D		3.6		mA
Quiescent current	Іват	3.6V, No input, No load, Class AB		6.9		mA
Shutdown current	Isd			0.1		uA
Input impedance per input pin	Rin			18		kΩ
	Av	R _{IN} = 0ohm, Class D		28.8		dB
Closed-loop voltage gain		R _{IN} = 0ohm, Class AB		22.8		dB
		Shutdown mode	0		0.2	V
CTRL terminal setting		Class AB mode, Charge Pump disabled	0.7		1.2	V
threshold voltage	Vctrl	Class D mode, Charge Pump adaptively enabled, ACF on	1.6		2.2	V
		Class D mode, Charge Pump adaptively enabled, ACF off	2.5		AVBAT	V
Start-up time ⁵	t _{ON}			80		ms
Over temperature protection point	OTP			150		°C

Charge Pump Specifications

Condition: VBAT = 2.7~5.5V, $T_A = 25^{\circ}$ C, Unless otherwise specified.

PARAMETER	SYMBOL	CONDITION	MIN	TYP	MAX	UNIT
Charge pump output voltage	PVDD			6.6		V
Switching frequency	fsw_сн			1100		kHz
Max output current	I _{PVDD}	VBAT=4.2V		2		А

³ Depending on parts and PCB layout, characteristics may be changed.

⁵ Power on, shutdown release, or the switching between Class AB and Class D

⁴ Stresses beyond those listed under absolute maximum ratings may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated under recommended operating conditions is not implied. Exposure to absolute–maximum–rated conditions for extended periods may affect device reliability.



Class D Audio Amplifier Specifications

Condition: VBAT = 3.7V, $T_A = 25^{\circ}$ C, $C_{IN} = 1uF$, $R_{IN} = 0k$, Av = 28.8dB, $R_L = 4\Omega$, $f_{IN} = 1kHz$, $C_{VBAT} = 1uF//10uF//470uF$, $C_{OUT} = 1uF//10uF//470uF$, $C_{FLY} = 4.7uF$, Unless otherwise specified.

PARAMETER	SYMBOL	CONDITION		MIN	TYP	MAX	UNIT
		VBAT=5V	THD+N = 10%		5.5		
		VBAT=5V	THD+N = 1%		4.5		Í Í
		VBAT=4.2V	THD+N = 10%		5.5		
Output Dowor	Da	VBAT=4.2V	THD+N = 1%		4.5		۱۸/
Output Power	Po	VBAT=3.7V	THD+N = 10%		4.3		- W
		VBAT=3.7V	THD+N = 1%		3.8		
		VBAT=3.3V	THD+N = 10%		3.3		
		VBAT=3.3V	THD+N = 1%		2.9		
Total Harmonic Distortion + Noise	THD+N	Po=1W R∟=4Ω	Ω, f=1kHz		0.08		%
	V _N	f=20Hz~20kHz, A weighted, Av=28.5dB			120		μVrms
Output Noise		f=20Hz~20kHz, A weighted, Av=25dB			100		μV _{rms}
Offset Voltage	Vos				±5		mV
Efficiency	-	VBAT=3.7V, Po=0.4W			84		%
	η	VBAT=3.7V, Po=2W			72		%
Switching frequency	fsw_D				380		kHz

Class AB Audio Amplifier Specifications

Condition: VBAT = 3.7V, $T_A = 25^{\circ}$ C, $C_{IN} = 1uF$, $R_{IN} = 0k$, Av = 22.8dB, $R_L = 4\Omega$, $f_{IN} = 1kHz$, $C_{VBAT} = 1uF//10uF//470uF$, $C_{OUT} = 1uF//10uF//470uF$, $C_{FLY} = 4.7uF$, Unless otherwise specified.

PARAMETER	SYMBOL	CONDITION		MIN	TYP	MAX	UNIT
		VBAT=5V			2.8		
		VBAT=4.2V	f=1kHz, R∟=4Ω,		2		
		VBAT=3.7V	THD+N=10%		1.5		
	D.	VBAT=3.3V			1.2		- W
Output Power	Po	VBAT=5V			2.3		
		VBAT=4.2V	f=1kHz, R∟=4Ω, THD+N=1%		1.6		
		VBAT=3.7V			1.2		
		VBAT=3.3V			0.9		
Total Harmonic Distortion + Noise	THD+N	PO=1W	RL=4Ω, f=1kHz		0.06		%
Output Noise	V _N	f=20Hz~20kHz, A weighted, Av=22.8dB			63		μV _{rms}
Output Noise		f=20Hz~20kHz, A weighted, Av=19dB			50		μV _{rms}
Offset Voltage	Vos				±5		mV
Efficiency	η	Po = 1W			61		%



TYPICAL OPERATING CHARACTERISTICS

Class D Mode, VBAT = 4.2V, f_{IN} = 1kHz, Load = 40hm, Po = 1W, unless otherwise specified.





Class AB Mode, VBAT = 4.2V, f_{IN} = 1kHz, Load = 40hm, Po = 1W, unless otherwise specified.





APPLICATION INFORMATION

The HT8313 is a highly efficient 5.5W Class-D audio power amplifier with anti-clipping function (ACF) for applications of battery-powered portable devices. It integrates a filter-less Class-D audio amplifier with an adaptive charge pump regulator. It operates from 2.7V to 5.5V supply. When operating with a 4.2V supply voltage, the HT8313 can deliver into a 4Ω load a maximum output power up to 5.5W with 10% THD+N.

In HT8313, the power supply rail of the Class-D amplifier output stage is internally boosted and regulated at 6.6V by an adaptive charge pump regulator, allowing for a much louder audio output than a stand-alone one directly connected to the battery. It makes HT8313 an ideal audio solution for portable devices, which are powered by a single-cell lithium battery while requiring higher audio loudness.

The ft8311 features ACF to constantly monitor and safeguard the audio outputs against the boosted supply voltage, preventing output clipping distortion, excessive power dissipation, or hazardous speaker over-load. Once an over-level condition is detected, the ACF lowers the voltage gain of the audio amplifier proportionally to eliminate output clipping distortion while maintaining a maximum dynamic range of the audio outputs allowed by the boosted supply voltage.

Class AB amplifier mode is also available for HT8313. Once the EMI Interference from class D and Boost Converter becomes an annoying problem, HT8313 can be changed into Class AB mode.

As specifically designed for portable device applications, the HT8313 incorporates a shutdown mode to minimize the power consumption by holding the CTRL pin to ground. It also includes comprehensive protection features against various operating faults such as over-current, over-temperature, and undervoltage for a safe and reliable operation.

1. Charge Pump Regulator

To allow for a much louder audio output, an integrated adaptive charge pump regulator is employed to boost PVDD, the power rail for the Class-D amplifier output stage. Whenever the audio outputs are higher than a prescribed level, the charge pump regulator will be activated to boost and regulate PVDD at 6.6V. In this case, the charge pump regulator operates in the regulation mode. For a proper operation, the boosted voltage PVDD generated by the charge pump regulator must be externally shorted to PVDD pins via a sufficiently wide metal trace on the system board.

On the other hand, when the audio outputs are less than a prescribed level for an extended period of time, the charge pump regulator will be de-biased and forced into the standby mode. In the standby mode, the amplifier output stage is powered directly by VBAT, the battery voltage, through an internal power switch. This adaptive nature of the charge pump regulator can greatly improve the power efficiency of HT8313 when playing audio and thus extends battery life.

1.1. Selection of Charge Pump Flying Capacitor (C_{FLY})

A nominal value of 4.7µF is recommended for the flying capacitors (between CP and CN) of the charge pump regulator. A low equivalent-series-resistance (ESR) ceramic capacitor, such as X7R or X5R, is recommended.

1.2. Selection of Charge Pump Output Capacitor (COUT)

For best performance, a 10μ F low ESR ceramic capacitor in parallel with a 1μ F ceramic capacitor is recommended for the output capacitor (C_{OUT}) of the charge pump regulator. For a better audio performance in large power situation, another tantalum or electrolytic capacitor (220 μ F or higher) can be paralleled.



2. Anti-Clipping Function (ACF) and Mode Configuration

Once the ACF function is enabled, HT8313 attenuates system gain to an appropriate value when an excessive input is applied, so as not to cause the clipping at the differential signal output. In this way, the output audio signal is controlled in order to obtain a maximum output level without distortion. And HT8313 also follows to the clips of the output waveform due to the decrease in the power-supply voltage.



Fig. 1 the ACF Function Operation Outline

The Attack time of ACF Function is a time interval until system gain falls to target attenuation gain -3dB when a big enough signal input. And the Release Time is a time from target attenuation gain to not working of ACF. The maximum attenuation gain is 10dB.

For HT8313, the attack time is 50ms, and the release time is 300ms.

3. Audio Amplifier Input Configuration

HT8313 is an amplifier with analog input (single-ended or differential). For a differential input between IN+ and IN- pins, signals input via DC-cut capacitors (C_{IN}) and input resistor (R_{IN} , optional). In class D mode, the input signal gain is calculated by

$$Av \approx 20 \times \log \frac{510k}{18k + R_{IN}}$$

In class AB mode, the input signal gain is calculated by

$$Av \approx 20 \times \log \frac{255k}{18k + R_{IN}}$$

And, the low pass cut-off frequency of input signal, can be calculated by

$$f_c \approx \frac{1}{2\pi (18k + R_{IN})C_{CIN}}$$



HT8313 Audio Amplifier Integrated with Charge Pump

For a single-ended input at IN+ pin, signal input via a DC-cut capacitor (C_{IN}) and input resistor (R_{IN} , optional). IN- pin should be connected to ground via a DC-cut capacitor and a input resistor (with the same value of C_{IN} and R_{IN}). The Gain and low pass Cut-off frequency are the same as the above case.



Fig. 2 (1) Differential Input;

(2) Single-ended Input

4. Working Mode Selection (CTRL Terminal)

HT8313 can work in different modes by setting the CTRL terminal, shown as follow.

Table. 1	CTRL Terminal Mode Control
----------	----------------------------

MODE	SYMBOL	CTRL Voltage			
MODE	SIMBOL	MIN.	TYP.	MAX.	UNIT
Class D mode, ACF OFF, Charge Pump adaptively enabled	V _{MOD1}	2.5		AVBAT	V
Class D mode, ACF ON, Charge Pump adaptively enabled	V _{MOD2}	1.6		2.2	V
Class AB mode, ACF off, Charge Pump disabled	V _{MOD3}	0.9	1.2	1.5	V
SD (Shutdown) Mode	V _{MOD4}	0	0	0.4	V

Notice that there's no internal pull-up or pull-down resistor.

5. Pop-Click Noise Reduction

The Pop-Click Noise Reduction Function of HT8313 works in the cases of Power-on, Power-off, Shutdown on, and Shutdown off. To achieve a more excellent noise reduction performance, it is recommended to use a DC-cut capacitor (C_{IN}) of 0.1µF or less.

Besides, POP noise can be minimal according to the following procedure of shutdown control.

During power-on, Shutdown mode is not cancelled until the power supply is stabilized enough.
Before Power-off, set Shutdown mode first.

The pop-click noise: Power-on/-off > Shutdown on/off.



Fig. 3 Pop-Click Noise Reduction by Shutdown



6. Protection Function

HT8313 has the protection functions such as Over-Current Protection function, Thermal Protection function, and Low Voltage Malfunction Prevention function.

(1) Over-current Protection function

When a short circuit occurs between one output terminal and Ground, PVDD, or the other output, the overcurrent protection mode starts up. In the over current protection mode, the differential output terminal becomes a high impedance state. Once the short circuit conditions are eliminated, the over current protection mode can be cancelled automatically.

(2) Thermal Protection function

When excessive high temperature of HT8313 (160°C) is detected, the thermal protection mode starts up. In the thermal protection mode, the differential output terminal becomes Weak Low state (a state grounded through high impedance).

(3) Low voltage Malfunction Prevention function

This is the function to establish the low voltage protection mode when AVBAT terminal voltage becomes lower than the detection voltage (V_{UVLL}) for the low voltage malfunction prevention. And the protection mode is canceled when AVBAT terminal voltage becomes higher than the threshold voltage (V_{UVLH}). In the low voltage protection mode, the differential output pin becomes Weak Low state (a state grounded through high impedance). HT8313 will start up within the start-up time (T_{ON}) when the low voltage protection mode is cancelled

7. Typical Application Circuits





8. Typical PCB Layout









PACKAGE

SOP10L-PP

<u>TOP VIEW</u> 正视图









SIDE VIEW

侧视图

	机械尺寸/mm							
			nsions					
	字符 SYMBOL	最小值 MIN	典型值 NOMINAL	最大值 MAX				
	Α	1,50	1,60	1.70				
	A1	0.04	-	0.12				
	A2	1.35	1.45	1.55				
	AЗ	0,65	0.70	0.75				
	b	0,35	-	0,50				
	C	0.19	-	0,25				
-	D	4.80	4.90	5.00				
	D1	3.20	3.30	3.40				
	Е	3.80	3,90	4,00				
	E1	5.80	6.00	6,20				
	E2	2.00	2,10	2,20				
	e		1.00 BSC					
	h	0,30	-	0,50				
	L	0.50	-	0.80				
	θ	0°	-	8°				

OUTLINE



IMPORTANT NOTICE 注意

Jiaxing Heroic Electronic Technology Co., Ltd (HT) reserves the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any products or services without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

嘉兴禾润电子科技有限公司(以下简称HT)保留对产品、服务、文档的任何修改、更正、提高、改善和其他改变,或停止 提供任何产品和服务,并不提供任何通知的权利。客户在下单和生产前应确保所得到的信息是最新、最完整的。

HT assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using HT components.

HT对相关应用的说明和协助以及客户产品的板级设计不承担任何责任。

HT products are not authorized for use in safety-critical applications (such as life support devices or systems) where a failure of the HT product would reasonably be expected to affect the safety or effectiveness of that devices or systems. HT的产品并未授权用于诸如生命维持设备等安全性极高的应用中。

The information included herein is believed to be accurate and reliable. However, HT assumes no responsibility for its use; nor for any infringement of patents or other rights of third parties which may result from its use.

本文中的相关信息是精确和可靠的,但HT并不对其负责,也不对任何可能的专利和第三方权利的侵害负责。

Following are URLs and contacts where you can obtain information or supports on any HT products and application solutions:

下面是可以联系到我公司的相关链接和联系方式:

嘉兴禾润电子科技有限公司

Jiaxing Heroic Electronic Technology Co., Ltd.

地址: 浙江省嘉兴市凌公塘路3339号JRC大厦A座三层
Add: A 3rd floor, JRC Building, No. 3339, LingGongTang Road, Jiaxing, Zhejiang Province
Sales: 0573-82583866, sales@heroic.com.cn
Support: 0573-82586151, support@heroic.com.cn
Fax: 0573-82585078
Website: www.heroic.com.cn; wap.heroic.com.cn
Wechat MP: HEROIC_JX
请及时关注禾润官方微信公众号,随时获取最新产品信息和技术资料!

