

13V,10A全集成同步升压转换器

13V,10A Fully-Integrated Synchronous Boost Converter

■ FEATURES

- Input voltage range V_{IN}: 2.7V to 13V
- Output voltage range V_{OUT}: 4.5V to 13V
- Switch peak current limit: 10A
- High Efficiency
 93% (V_{IN} = 7.4V, V_{OUT}=12V, I_{OUT} =3A)
 92% (V_{IN} = 3.6V, V_{OUT}=9V, I_{OUT} =1A)
- 1.0µA current consumption during shutdown
- Fixed switching frequency: ~450kHz
- Output overvoltage protection (at 14V), cycle-bycycle overcurrent protection, thermal shutdown protection
- Pb-free Packages, ESOP10

- ·输入电压范围V_{IN}: 2.7V-13V
- ·输出电压范围Vour: 4.5V-13V
- ·内部固定峰值电流: 10A
- · 高转换效率:
 - 93% (V_{IN} = 7.4V, V_{OUT} =12V, I_{OUT} =3A) 92% (V_{IN} = 3.6V, V_{OUT} =9V, I_{OUT} =1A)
- ·低关断功耗,关断电流1uA
- ·内部固定开关频率:~450kHz
- ·输出过压 (14V)、逐周期过流、热关断等保护
- ·ESOP10, 无铅封装

■ APPLICATIONS

- Wireless/ Speakers
 Portable Speakers
- Quick Charge Power Bank
 E-Cigarette
- Power Interface (USB Type-C, Thunderbolt)
- POS Terminal
- Tablet PC/Note Book
- · 无线音箱

- · 便携式音箱
- 快充移动电源
- ・电子烟
- · USB TYPE-C 电源传输
- 拉杆音箱
- · 平板电脑, 笔记本电脑
- ·POS机终端



DESCRIPTION

The HT71663 is a high-power density, fully integrated synchronous boost converter with a $16m\Omega$ power switch and a $23m\Omega$ rectifier switch to provide a high efficiency and small size solution in portable systems. The HT71663 has wide input voltage range from 2.7 V to 13 V to support applications with single cell and two cell Lithium batteries. The device has 10A switch current capability and can provide an output voltage up to 13V.

The HT71663 uses adaptive constant off-time peak current control topology to regulate the output voltage. In moderate to heavy load condition, it works in the PWM mode. In light load condition, the device operates in PFM mode to improve the efficiency. The switching frequency in the PWM mode is fixed.

In addition, the device provides 14V output overvoltage protection, cycle-by-cycle overcurrent protection, and thermal shutdown protection.


HT71663是一款高功率、全集成升压转换器,集成16mΩ功率开关管和23mΩ同步整流管,为便携式系统提供高效的小尺寸解决方案。

HT71663具有2.7V至13V宽输入电压范围,可为采用单节或两节锂电池的应用提供支持。该器件具备10A开关电流能力,并且能够提供最高13V的输出电压。

HT71663采用自适应恒定关断时间峰值电流控制拓扑结构来调节输出电压。在中等到重负载条件下,HT71663工作在PWM模式。在轻负载条件下,该器件工作在可提高效率的PFM模式。

此外,该器件还提供有14V输出过压保护、逐周期过流保护和热关断保护。

■ TYPICAL APPLICATION







■ ORDERING INFORMATION

Part Number	Package Type	Package Abbr.	Marking	Shipping Package / MOQ
HT71663SPER	ESOP10	SPE	HT71663 YYYMAAB ¹	Tape and Reel / 2500

Part Number



Production Tracking Code




Copyright©2024, Heroic Technology

¹ YYYMAAB is production tracking code



■ TERMINAL CONFIGURATION



Top View

■ TERMINAL FUNCTION

Terminal No.	Name	I/O ¹	Description
1	VCC	О	Output of the internal regulator. A ceramic capacitor of 2.2uF is required between this pin and ground. 接2.2uF到地。
2	EN	I	Enable logic input. Logic high level enables the device. Logic low level disables the device and turns it into shutdown mode. 使能输入,接高电平使能,低电平关断
3	VIN	P	IC power supply input. 电源输入脚
4	SW	P	The switching node pin of the converter. 升压开关节点
5	BOOT	О	Power supply for high-side MOSTFET gate driver. A ceramic capacitor of $0.1\mu F$ must be connected between this pin and the SW pin. 接 $0.1\mu F$ 电容到SW
6, 10	NC	-	No connection, connect to GND. 内部无连接,可连接到地。
7	VOUT	P	Boost converter output. 升压输出
8	FB	I	Voltage feedback. 电压反馈
9	COMP	О	Output of the internal error amplifier, the loop compensation network should be connected between this pin and the AGND pin. 接阻容补偿网络到地。
EP	GND	G	Provides both electrical and thermal connection from the device to the board. A matching ground pad must be provided on the PCB and the device connected to it via solder. For proper electrical operation, this ground pad must be connected to the system ground. 既是地,又是散热PAD

¹ I: Input; O: Output; G: Ground; P: Power; BST: BOOT Strap; OD: Open drain



■ SPECIFICATIONS¹

Absolute Maximum Ratings*2

PARAMETER BOOT EN, SW, Vout, Vin VCC, COMP FB		Symbol	MIN	MAX	UNIT
	BOOT		-0.3	SW+7	
Voltage range	EN, SW, Vout, Vin	,	-0.3	14.2	\/
	VCC, COMP	/	-0.3	7	V
	FB		-0.3	3.6	
Operating temperature range		TA	-40	85	$^{\circ}$
Operating junction temperature range		TJ	-40	150	$^{\circ}$
Storage temperature range		T _{STG}	-50	150	$^{\circ}$

• Recommended Operating Conditions

PARAMETER	Symbol	CONDITION	MIN	TYP	MAX	UNIT
IC power supply voltage range	V _{IN}		2.7		13.2	V
Output voltage range	Vouт		4.5		13.8	V
Inductance, effective value	L		0.47	2.2	10	μΗ
Input capacitance, effective value	Cı		10			μF
Output capacitance, effective value	Co		6.8	47	1000	μF
Operating temperature	Ta		-40	25	85	$^{\circ}$ C
Operating junction temperature	TJ		-40		125	$^{\circ}$ C

_

¹ Depending on parts and PCB layout, characteristics may be changed.

² Stresses beyond those listed under absolute maximum ratings may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated under recommended operating conditions is not implied. Exposure to absolute—maximum—rated conditions for extended periods may affect device reliability.



Electrical Characteristics*1

Condition: Ta = 25° C, V_{IN} = 2.7V-13.2V, V_{OUT} =4.5-13.2V, unless otherwise specified.

Power Supply

PARAMETER	Symbol	CONDITION	MIN	TYP	MAX	UNIT
Input power voltage range	VIN		2.7		13.2	V
IC power supply voltage range	V_{IN}		2.7		13.2	V
Under-voltage lockout	V	VIN rising		2.5		V
(UVLO) threshold	V _{IN_UVLO}	VIN falling		2.3		V
VIN UVLO hysteresis	V _{IN_HYS}			200		mV
VCC UVLO threshold	Vcc_uvlo			2.1		V
Operating quiescent current from V _{IN}	l-	IC enabled, no load, V _{FB} = 1.3V, V _{OUT} =		1		
Operating quiescent current from V _{OUT}	lα	12V		150		uA
Shutdown current into V _{IN}	Isp	IC disabled, no load, no feedback resistor divider		1		uA
VCC regulation	V	V _{IN} = 4.0V, V _{OUT} = 12V, light load		5.3		V
VCC regulation	Vcc	V _{IN} = 4.0V, V _{OUT} = 12V, I _{LOAD} = 1A		5.05		V

EN and EMI Input

PARAMETER	Symbol	CONDITION	MIN	TYP	MAX	UNIT
EN high threshold voltage	V _{ENH}				1.2	V
EN low threshold voltage	V _{ENL}		0.4			V
EN internal pull-down resistance	R _{EN}			1300		kΩ

OUTPUT

PARAMETER	Symbol	CONDITION	MIN	TYP	MAX	UNIT
Output voltage range	Vouт		4.5		13.2	V
Output overvoltage protection	V _{OVP}			14.4		V
Reference voltage at the FB pin	V _{REF}		1.17	1.204	1.23	V
Soft-start charging current	I _{SS}			5		uA

ERROR AMPLIFIER

PARAMETER	Symbol	CONDITION	MIN	TYP	MAX	UNIT
COMP pin sink current	Isink	V _{FB} = V _{REF} +200 mV, V _{COMP} = 1.5 V		20		uA
COMP pin source current	Isource	V _{FB} = V _{REF} -200 mV, V _{COMP} = 1.5 V		20		uA
High clamp voltage at the COMP pin	V _{CC_LPH}	$V_{FB} = 1 \text{ V}, \text{ R}_{ILIM} = 100 \text{ k}\Omega$		2.14		>
Low clamp voltage at the COMP pin	V _{CC_LPL}	V_{FB} = 1.5 V, R_{ILIM} = 100 k Ω ,		0.94		٧
Error amplifier transconductance	GEA	V _{COMP} = 1.5 V		204		uA/V

¹ Depending on parts and pattern layout, characteristics may be changed





PARAMETER	Symbol	CONDITION	MIN	TYP	MAX	UNIT
POWER SWITCH	-					l
MOSFET on-	D	High-side MOSFET		23		mΩ
resistance	R _{DS(on)}	Low-side MOSFET		16		mΩ
CURRENT LIMIT						
Peak switch current limit	I _{LIM}			10		А
Reference voltage at the ILIM pin	VILIM			1.204		V
SWITCHING FREQUEN	ICY					
Switching frequency	fsw	V _{IN} = 3.7V, V _{OUT} = 12V		430		kHz
Minimum on-time	t _{ON_min}	$V_{IN} = 3.6V, V_{OUT} = 12V$		490		ns
THERMAL SHUTDOWN	١					
Thermal shutdown threshold	T _{SD}			160		$^{\circ}$ C
Thermal shutdown hysteresis	T _{SD_HYS}			20		$^{\circ}\!\mathbb{C}$




■ TYPICAL OPERATING CHARACTERISTICS

Condition: L = 2.2uH, Output Capacitor = 1uF//10uF//10uF//220uF, otherwise specified.









■ APPLICATION INFORMATION

1 Enable and Startup (EN and SS pin)

The HT71663 has an adjustable soft start function to prevent high inrush current during start-up. The soft start time is normally 5ms.

When the EN pin is pulled into logic low, the HT71663 goes into the shutdown mode and stops switching. Only when EN pin is pulled into logic high, the HT71663 works.

HT71663 具有软起动功能,防止启动时的高浪涌电流。软启动时间一般约 5ms

EN 为芯片使能脚, EN 拉低, 芯片进入关断模式, 停止开关; EN 拉高, 芯片进入工作状态。

2 Switching Frequency

This device features a fix switching frequency. The switching frequency is determined by Vin and Vout. The switching frequency is usually around 450kHz.

HT71663 的开关频率内部固定,与 Vin 和 Vout 相关。其频率一般约为 450kHz。

3 Peak Current Limit

To avoid an accidental large peak current, an internal cycle-by-cycle current limit is adopted. The low-side switch is turned off immediately as soon as the switch current touches the limit. The peak switch current limit is usually around 10A.

芯片采用逐周期电流限制,避免意外的大峰 值电流。当开关电流达到设置的限流值,低侧开 关管立即断开。峰值开关电流一般约为 10A。

4 Output Voltage Setting (FB pin)

The output voltage is set by an external resistor divider (R_{UP} , R_{DN} in the Typical Application Circuit):

输出电压由外部电阻分压器(R_{UP},典型应用电路中的 R_{DN})设置:

$$V_{OUT} = V_{REF} \times (1 + \frac{R_{UP}}{R_{DN}})$$

Where $V_{REF} = 1.204V$.

Some typical output voltages can be set as the following parameters.

Equation 1

其中 V_{RFF} = 1.204V。

部分典型电压可参考如下:

Table 1 Typical Output Voltage Settings

V _{оит} (V)	$R_UP(\Omega)$	$R_{DN}(\Omega)$
5.3	510k	150k
7.4	510k	100k
9.4	510k	75k
12.2	510k	56k

5 Inductor Selection (SW pin)

The inductor is the most important component in switching power regulator design. Three most important specifications to the performance of the inductor are the inductor value, DC resistance, and saturation current.

To be simplified, the inductor value can be set as 2.2uH which can be used in most cases.

The rated current, especially the saturation current should be larger than the peak current during the whole operation. The peak current can be calculated as follows.

电感是该芯片的关键器件,影响性能的主要是其电感值,直流阻抗,饱和电流。

对于电感值,使用 2.2uH 的电感可以满足大部分应用。

对于额定电流,特别是饱和电流,必须大于 所有工作条件下的最大峰值电流,最大峰值电流 计算如下:



$$\begin{split} I_{Lpeak} &= I_{DC} + \frac{I_{PP}}{2} \\ I_{DC} &= \frac{V_{OUT} \times I_{OUT}}{V_{IN} \times \eta} \\ I_{PP} &= \frac{1}{L \times (\frac{1}{V_{OUT} - V_{IN}} + \frac{1}{V_{IN}}) \times f_{SW}} \end{split}$$

Boost converter efficiency is affected significantly by the inductor's DC resistance (DCR), equivalent series resistance (ESR) at the switching frequency, and the core loss. An inductor with lower DCR and ESR would increase the efficiency significantly.

The inductor should be placed as close as possible to the SW pin. For a lower EMI radiation, connecting a resistor and a capacitor in series to the ground would be helpful. 10hm resistor and 3.3nF capacitor would be recommended in most cases.

6 Input Capacitor Selection (VIN, VCC pin)

For good input voltage filtering and small voltage ripple, we recommend low-ESR capacitors of 1uF//10uF//10uF//220uF ("//" represents paralleled) be placed as close as possible to the inductor.

The VIN pin is the power supply for the HT71663, a 1uF paralleled with 10uF ceramic capacitor should be placed as close as possible to the VIN pin. A resistor of 100R is recommended between input power supply and VIN pin so that the power supply of HT71663 would be more stable. An extensive power supply such as the logic power supply connecting to VIN would be another choice.

The VCC pin is the output of internal LDO. A ceramic capacitor of 2.2uF is required at the VCC pin to get a stable operation of LDO.

7 Output Capacitor Selection (VOUT pin)

To be simplified, we recommend low-ESR capacitors of 1 u F // 10 u F // 10 u F // 470 u F ("//" represents paralleled) be placed as close as possible to VOUT pin for small output voltage ripple.

In detail, for the require output voltage ripple, use the following equations to calculate the minimum required effective capacitance C_{OUT}

Equation 2

Equation 3

Equation 4

升压效率受电感的直流阻抗、开关频率下的等效 ESR、磁心损耗等影响。选择小的 DCR 和 ESR 可提升效率。

电感应尽可能靠近 SW 引脚放置,并靠近 SW 引脚放置 10hm 串联 3.3nF 到地。

为了良好的储能和滤波以及减小电压波动, 建议电源输入端使用 luF//10uF//10uF//220uF 组 合,放置在靠近电感的大电流路径上。

VIN 脚是 HT71663 的电源供电端, 1uF 并联 10uF 对地电容放置在靠近 VIN 脚。输入电源和 VIN 脚之间可以串联 1 个 100R 电阻,已稳定 VIN 电压。VIN 还可以有系统中的逻辑电源供电。

VCC 是内部 LDO 输出,接 2.2uF 电容到地。

简单来说,升压输出到地滤波电容建议使用 1uF//10uF//10uF//470uF 的组合,尽量靠近 Vout 引脚放置。

具体的,可以根据需要的输出电压纹波,得 到需要的输出电容值:

$$V_{ripple_dis} = \frac{(V_{OUT} - V_{IN_{MIN}}) \times I_{OUT}}{V_{OUT} \times f_{SW} \times C_{OUT}}$$
 Equation 5

$$V_{ripple_ESR} = I_{Lpeak} \times R_{C_ESR}$$
 Equation 6



Where

- Vripple_dis is output voltage ripple caused by charging and discharging of the output capacitor.
- Vripple_ESR is output voltage ripple caused by ESR of the output capacitor.
- $V_{IN\ MIN}$ is the minimum input voltage of boost converter..
- V_{OUT} is the output voltage..
- I_{OUT} is the output current.
- I_{Lpeak} is the peak current of the inductor.
- f_{SW} is the converter switching frequency.
- R_{C ESR} is the ESR of the output capacitors.

8 Loop Stability (COMP pin)

The HT71663 requires external compensation, which allows the loop response to be optimized for each application. The COMP pin is the output of the internal error amplifier. An external compensation network comprised of resister R_{C} , ceramic capacitors C_{C} and C_{P} is connected to the COMP pin.

To be simplified, R_C is $56k\Omega$, C_C is 3.3nF, and C_P is 47pF. But notice that this setting can only be adopted in most cases. In detail, the compensation network parameters can be calculated as follows.

(1) Set the cross over frequency, f_c

The first step is to set the loop crossover frequency, $f_{\rm C}$. The higher crossover frequency, the faster the loop response is. It is generally accepted that the loop gain cross over no higher than the lower of either 1/10 of the switching frequency, $f_{\rm SW}$, or 1/5 of the RHPZ frequency, $f_{\rm RHPZ}$. It's proper to use a fixed parameter of 10kHz for $f_{\rm C}$.

$$f_{RHPZ} = \frac{R_O \times (1 - D)^2}{2\pi \times L}$$

(2) Set the compensation resistor, R_C.

$$R_C = \frac{2\pi \times V_{OUT} \times R_{sense} \times f_C \times C_O}{(1-D) \times V_{REF} \times G_{EA}}$$

(3) Set the compensation resistor, C_C.

$$C_C = \frac{R_O \times C_O}{2 \times R_C}$$

(4) Set the compensation resistor, C_P.

$$C_P = \frac{R_{ESR} \times C_O}{R_C}$$

Equation 10

其中:

- Vripple_dis 是对电容充放电引起的输出电压 纹波.
- Vripple_ESR 是输出电容ESR引起的输出电压纹波.
- V_{IN MIN} 是最小输入电压.
- Vour 是输出电压.
- Iout 是输出电流.
- ILpeak 是电感峰值电流.
- fsw 是开关频率.
- R_{C ESR} 是输出电容 ESR.

HT71663 需要外部补偿,在 COMP 引脚外接 Rc, Cc, Cp。简单来说, Rc=56k Ω , Cc=3.3nF, Cp=47pF 可以满足大部分应用。以下是补偿网络的计算过程:

(1) 设置交叉频率 fc

Fc 越大,响应越快。一般其设置为开关频率的 1/10 或 1/5 的 f_{RHPZ},或直接为 10kHz.

Equation 7

(2) 设置补偿网络 Rc

Equation 8

(3) 设置补偿网络 Cc

Equation 9

(4) 设置补偿网络 Cp



If the C_P is less than 10pF, it can be left open.

- Ro is the output load resistance.
- D is the switching duty cycle. 1 D = V_{IN} / V_{OUT}
- R_{sense} is the equivalent internal current sense resistor, which is 0.091 Ω .
 - C_O is output capacitor.
- $\,^{ullet}$ V_{REF} is the reference voltage at the FB pin, which is 1.204V.
- $\bullet~$ G_{EA} is the amplifier's transconductance, which is 204uA/V.
- \bullet $\,$ R $_{\text{ESR}}$ is the equivalent series resistance of the output capacitor.

9 Selecting the Bootstrap Capacitor (BOOT pin)

The bootstrap capacitor (C_{BST}) between the BOOT and SW pin supplies the gate current to charge the high-side FET device gate during each cycle's turn-on and supplies charge for the bootstrap capacitor. The recommended value of the bootstrap capacitor is $0.1\mu F$ to $1\mu F$. C_{BST} should be a good quality, low ESR, ceramic capacitor located at the pins of the device to minimize potentially damaging voltage transients caused by trace inductance. A value of $0.1\mu F$ can be used in most cases.

10 Protection Function

10.1 Under-voltage Lockout (UVLO)

The UVLO circuit prevents the device from malfunctioning at low input voltage and the battery from excessive discharge. The HT71663 has both VIN UVLO function and VCC UVLO function. It disables the device from switching when the falling voltage at the VIN pin trips the UVLO threshold $V_{\rm IN_UVLO},$ which is typically 2.3V. The device starts operating when the rising voltage at the VIN pin is 200mV above the $V_{\rm IN_UVLO}.$ It also disables the device when the falling voltage at the VCC pin trips the UVLO threshold $V_{\rm CC_UVLO},$ which is typically 2.1V.

10.2 Over-voltage Protection

If the output voltage at the VOUT pin is detected above 14.4 V (typical value), the HT71663 stops switching immediately until the voltage at the VOUT pin drops the hysteresis value lower than the output overvoltage protection threshold. This function prevents overvoltage on the output and secures the circuits connected to the output from excessive overvoltage.

10.3 Thermal Shutdown

A thermal shutdown is implemented to prevent damages due to excessive heat and power dissipation. Typically, the thermal shutdown happens at a junction temperature of 150°C. When the thermal shutdown is triggered, the device stops switching until the junction temperature falls below typically 130°C, then the device starts switching again.

如果 Cp 小于 10pF,可以悬空。

其中 Ro 是输出负载;

D 是占空比, 1 - D = V_{IN} / V_{OUT}

 R_{sense} 是内部等效电流感应电阻,0.091 Ω

Co 是输出电容

VREF 是 FB 电压, 1.204V

GEA 是跨导, 204uA/V

R_{FSR} 是输出电容的等效串联电阻。

BOOT 和 SW 之间需放置一个 C_{BST} 电容,用于高端管开启时的栅极驱动。一般使用 0.1uF~1uF,大部分情况下可使用 0.1uF 电容。

HT71663 具有 VIN 和 VCC 欠压保护。当 VIN 小于 V_{IN_UVLO}(典型 2.3V)时,器件停止开关,直至 VIN 大于 V_{IN_UVLO}(典型 2.5V),器件重新工作。当 VCC 小于 V_{CC_UVLO}(典型 2.1V)时,器件同样停止工作。


当 VOUT 电压高于 14.4V (典型值), HT71663 停止工作,直到 VOUT 低于 14V (典型值)。


芯片具有过温关断保护功能。当结温大于 160℃(典型值),芯片关断;当结温低于140℃ (典型值),芯片恢复工作。




■ PACKAGE OUTLINE

TOP VIEW 正视图






SIDE VIEW 侧视图




		です/mm	
		nsions	
字符	最小值	典型值	最大值
SYMBOL	MIN	NOMINAL	MAX
Α	1,50	1.60	1.70
A1	0.04	_	0.12
A2	1.35	1.45	1.55
А3	0.65	0.70	0.75
b	0,35	-	0,50
C	0.19	_	0.25
D	4.80	4.90	5.00
D1	3.20	3.30	3.40
E	3.80	3.90	4.00
E1	5.80	6.00	6.20
E2	2.00	2.10	2.20
е		1.00 BSC	,
h	0,30	_	0.50
L	0.50	_	0.80
θ	0°	_	8°

■ TAPE AND REEL INFORMATION




编带 PIN1 方位象限分配 Quadrant Assignments for Pin1 Orientation in Tape



器件料号 Part No.	封装 类型 Package Type	封装 标识 Package Code	引脚 数 Pins	SPQ	料盘 直径 D _R (mm)	料盘 宽度 W1 (mm)	A0 (mm)	B0 (mm)	K0 (mm)	P1 (mm)	W (mm)	Pin1 象限 Quadrant
HT71663SPER	ESOP	SPE	10	250 0	330	12.5	6.55	5.25	2	8	12	Q1



■ TAPE AND REEL BOX INFORMATION



器件料号 Part No.	封装类型 Package Type	封装标识 Package Code	引脚数 Pins	SPQ	长度 Length (mm)	宽度 Width (mm)	高度 Height (mm)
HT71663SPER	ESOP	SPE	10	5000	380	340	60

IMPORTANT NOTICE

注意

Heroic Electronic Technology (Jiaxing) Co., Ltd (HT) reserves the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any products or services. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

禾润电子科技(嘉兴)股份有限公司(以下简称HT)保留对产品、服务、文档的任何修改、更正、提高、改善和其他改变,或停止提供任何产品和服务的权利。客户在下单和生产前应确保所得到的信息是最新、最完整的。

HT assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using HT components.

HT对相关应用的说明和协助以及客户产品的板级设计不承担任何责任。

HT products are not authorized for use in safety-critical applications (such as life support devices or systems) where a failure of the HT product would reasonably be expected to affect the safety or effectiveness of that devices or systems.

HT的产品并未授权用于诸如生命维持设备等安全性极高的应用中。

The information included herein is believed to be accurate and reliable. However, HT assumes no responsibility for its use; nor for any infringement of patents or other rights of third parties which may result from its use.

本文中的相关信息是精确和可靠的,但HT并不对其负责,也不对任何可能的专利和第三方权利的侵害负责。

Following are URLs and contacts where you can obtain information or supports on any HT products and application solutions:

下面是可以联系到我公司的相关链接和联系方式:

禾润电子科技(嘉兴)股份有限公司 Heroic Electronic Technology (Jiaxing) Co., Ltd.

地址: 浙江省嘉兴市凌公塘路3339号JRC大厦A座三层

Add: A 3rd floor, JRC Building, No. 3339, LingGongTang Road, Jiaxing, Zhejiang Province

Sales: 0573-82585539, sales@heroic.com.cn Support: 0573-82586151, support@heroic.com.cn

Fax: 0573-82585078

Website: www.heroic.com.cn; wap.heroic.com.cn

Wechat MP: HEROIC_JX

请及时关注禾润官方微信公众号,随时获取最新产品信息和技术资料!

