

## 带有3.3V, 150mA LDO输出的100V输入, 3.5A开关限流降压变换器

100V Input, 3.5A, Switching Current Limit Step-Down Converter with a 3.3V, 150mA LDO

### ■ FEATURES

- Wide 5V to 100V Input Range
- 3.5A Typical Peak Switching Current Limit
- Integrated a 3.3V, 150mA LDO
- Hysteretic Control: No Compensation
- Up to 1MHz Switching Frequency
- Short-Circuit Protection (SCP) with Integrated High-Side MOSFET
- 200 $\mu$ A Quiescent Current
- Thermal Shutdown
- Packages: Pb-free Packages, ESOP8
- 宽输入电压: 5V – 100V
- 峰值开关电流限值典型3.5A
- 内置3.3V, 150mA LDO
- 滞后电压控制模式, 无需补偿
- 最高1MHz开关频率
- 集成高端MOSFET的短路保护
- 200 $\mu$ A静态电流
- 过热关断保护
- ESOP8封装

### ■ APPLICATIONS

- Scooters, E-Bike Control Power Supplies
- Solar Energy Systems
- Automotive System Power
- Industrial Power Supplies
- High-Power LED Drivers
- GPS Trackers
- 电动车控制电源
- 汽车系统电源
- 大功率LED驱动器
- 太阳能系统
- 工业电源
- GPS追踪器

## DESCRIPTION

The HT7887 is a high-voltage, step-down, switching regulator that delivers up to 2A of continuous current to the load. It integrates a high-side, high-voltage, power MOSFET with a current limit of 3.5A, typically. The wide 5V to 100V input range accommodates a variety of step-down applications, making it ideal for automotive, industry, and lighting applications. Hysteretic voltage-mode control is employed for very fast response. The HT7887 also integrates a 150mA LDO which can provide 3.3V power rail for the system.

The switching frequency can be up to 1MHz, allowing for small component size. Thermal shutdown and short-circuit protection (SCP) provide reliable and fault-tolerant operations. A 200 $\mu$ A quiescent current allows the HT7887 to be used in battery-powered applications.



The HT7887 is available in ESOP8 package.

HT7887是一款高压降压开关稳压器,可向负载提供高达2A的连续电流。它集成了高压的高端功率MOSFET,电流限制通常为3.5A。其极宽的5V至100V输入电压范围能适应各种降压应用,使其成为汽车、工业和照明应用的理想选择。迟滞电压模式控制的应用,使其具有良好的瞬态响应能力。HT7887集成了一个输出3.3V, 150mA的LDO。

开关频率可高达1MHz,从而允许小尺寸的外围器件。过热保护和短路保护(SCP)使芯片具有较好的可靠性和容错机制。200 $\mu$ A的静态电流允许HT7887用于电池供电的应用中。

该产品提供ESOP8封装。

## TYPICAL APPLICATION



## 关于 HT7887 的注意事项

HT7887 的输出电容（C<sub>OUT</sub>）是实现平滑输出电压所必需的，并且对其 ESR 有较为严格的要求。如规格书所述，输出电容的 ESR 应足够大，否则，系统可能会以意外的方式运行，并且电流纹波可能非常高。一般建议的输出电容器 ESR 范围为 100mΩ 至 250mΩ，在整个工作条件、工作温度范围内。具体选择如下：

### （1）使用陶瓷电容或电解电容（推荐方式）


使用陶瓷电容或电解电容器时，FB 通过正向电阻、电容（C9 和 R6）连接到 SW，如典型应用图。通过调整 R6 和 C10 的值，可以改变 SW 的频率， $f_{SW} \propto \frac{1}{R_6 C_{10}}$ ，即增大 R6 或 C10，fsw 减小。建议 fsw 设置在约 200kHz~300kHz。

### （2）选择使用钽电容

输出电容使用 0.1μF + 2.2μF + 100μF 钽电容的并联组合，钽电容可使用 593D107X9010C2T3 或类似型号，其标称的 ESR 为 200mΩ

### （3）使用陶瓷电容并联电阻

由于钽电容价格昂贵，更多客户倾向于使用廉价的电解电容或陶瓷电容。由于电解电容的温度特性较差，一般不建议使用。使用陶瓷电容时，其 ESR 较小，不足以提供足够的 ESR 以使 HT7887 稳定运行，需要在陶瓷电容上串联一个电阻 R<sub>s</sub>（100~250mΩ），且后级没有更多电容（更多电容会同步影响 ESR），如下图：



## HT7887 Layout 建议



- （1）将输入电容器、二极管和 HT7887（VIN、SW 和 PGND）尽可能靠近；
- （2）输入电容建议至少放置一个电解电容（至少 10μF，耐压≥输入最高电压\*1.5）；
- （3）保持电源轨迹非常短且相当宽，特别是对于 SW 节点。

这有助于大大降低 SW 节点上的电压尖峰，并降低 EMI 噪声水平。


- （4）FB 走线尽可能远离电感和功率走线（如 SW 节点）。
- （5）将直径为15mil、间距为40mil（中心之间的距离）的热通孔放置在裸露的焊盘下方，以改善热传导。

**ORDERING INFORMATION**

Part Number	Package Type	Marking	Operating Temperature Range	Shipping Package / MOQ
HT7887SPER	ESOP8 (SPE)	HT7887SP YYYMAAB <sup>1</sup>	-40℃ ~ 125℃	Tape and Reel / 2500pcs

**Part Number**

**Production Tracking Code**


## ■ TERMINAL CONFIGURATION



Top View

## ■ TERMINAL FUNCTION

Terminal No.	Name	Description
1	FB	Feedback. FB is the input to the voltage hysteretic comparators. The average FB voltage is maintained at 200mV by loop regulation. 反馈。FB是电压迟滞比较器的输入。通过环路调节，FB电压保持在平均200mV
2	EN	Enable input. Pull EN below the specified threshold to shut down the HT7887. Pull EN above the specified threshold or leave EN floating to enable the HT7887. 使能脚。将EN拉到阈值以下以关闭HT7887。将EN拉至阈值以上或悬空，以启用HT7887。
3	VIN	Input supply for the buck. VIN supplies power to all of the internal control circuitries, both BST regulators, and the high-side switch. A decoupling capacitor to ground must be placed close to VIN to minimize switching spikes. 降压的输入电源。VIN为所有内部控制电路、BST调节器和高端管供电。接地滤波电容必须放置在VIN附近，以减少开关尖峰
4	BST	Bootstrap. BST is the positive power supply for the internal, floating, high-side MOSFET driver. Connect a bypass capacitor between BST and SW. BST是内部高端MOSFET驱动器的正电源。在BST和SW之间连接一个旁路电容器。
5	SW	Switch node. SW is the output from the high-side switch. A low forward voltage Schottky rectifier to ground is required. The rectifier must be placed close to SW to reduce switching spikes. SW是高低管的输出。需要接低正向电压的肖特基二极管到地。二极管必须靠近SW，以减少开关尖峰
6	LDOI	Input supply for internal LDO, connect to VOUT. LDO的输入电源，可连接至VOUT。
7	LDOO	Output of LDO, at least a 1uF ceramic cap should be connected. LDO输出，接1uF滤波器。
8	NC	No connection, connect to GND or floating. 内部无连接，外部接地或悬空。
EP	GND	Provides both <b>electrical and thermal connection</b> from the device to the board. <b>A matching ground pad must be provided on the PCB and the device connected to it via solder.</b> For proper electrical operation, this ground pad must be connected to the system ground. 既是地，又是散热PAD

## ■ SPECIFICATIONS<sup>1</sup>

### ● Absolute Maximum Ratings<sup>2</sup>

PARAMETER	Symbol	MIN	TYP	MAX	UNIT
Power supply voltage for VIN	VIN	-0.3		100	V
Power supply voltage for VIN, transient <100ns		-0.3		120	V
Power supply voltage for LDO1	V <sub>LDO1</sub>	-0.3		36V	
Switch voltage	SW	-0.5 (-7V for 10ns)		V <sub>IN</sub> +0.5	V
BST to SW		-0.3		6	V
All other pins		-0.3		6	V
Moisture Sensitivity Level (MSL)			MSL3		
Ambient Operating Temperature	T <sub>A</sub>	-40		125	°C
Junction Temperature	T <sub>J</sub>	-40		150	°C
Storage Temperature	T <sub>STG</sub>	-65		150	°C

### ● Recommended Operating Conditions

PARAMETER	Symbol	CONDITION	MIN	TYP	MAX	UNIT
Power supply voltage for VIN	VIN		5		95	V
Power supply voltage for LDO1	V <sub>LDO1</sub>		3		30	V
EN voltages			0		5	V
Maximum switching frequency	f <sub>sw</sub>				1M	Hz
Ambient Operating Temperature	T <sub>a</sub>		-40		125	°C

### ● Electrical Characteristics

VIN = 60V, TA = +25°C, unless otherwise noted. Specifications over temperature are guaranteed by design and characterization.

PARAMETER	Symbol	CONDITION	MIN	TYP	MAX	UNIT
VIN UVLO threshold	V <sub>UVLO</sub>			4.7		V
VIN UVLO hysteresis	V <sub>hys</sub>			0.3		V
Shutdown supply current	I <sub>SD</sub>	V <sub>EN</sub> = 0V		5		μA
Quiescent supply current	I <sub>Q</sub>	No load, V <sub>FB</sub> = 250mV, from VIN pin		200		μA
		From LDO1 pin		2		uA
Upper switch on resistance	R <sub>DS(ON)</sub>	V <sub>BST</sub> - V <sub>SW</sub> = 5V		380		mΩ
Upper switch leakage current	I <sub>SWLK</sub>	V <sub>EN</sub> = 0V, V <sub>SW</sub> = 0V		0.01		μA
Current limit	I <sub>PK</sub>	V <sub>FB</sub> = 150mV, HT7887		3.5		A
EN up threshold	V <sub>ENH</sub>			1.8		V
EN threshold hysteresis	V <sub>ENHY</sub>			400		mV
EN input current	I <sub>ENI</sub>	V <sub>EN</sub> = 5V		0.01		μA
EN pull-up current	I <sub>ENS</sub>	EN = 2V		2		μA
LDO Output voltage	V <sub>LDOO</sub>			3.3		V
LDO current limit	I <sub>LDO</sub>		150			mA
Load regulation				0.05		%
Feedback voltage threshold high	V <sub>FBH</sub>	4.5V < VIN < 95V, V <sub>FB</sub> rising from 0V until V <sub>SW</sub> < 30V		215		mV
Feedback voltage threshold low	V <sub>FBL</sub>	4.5V < VIN < 95V, V <sub>FB</sub> falling from 0.25V until V <sub>SW</sub> > 30V		185		mV
FB input current	I <sub>FB</sub>	V <sub>FB</sub> = 5V or 0V	-300		300	nA


<sup>1</sup> Depending on parts and PCB layout, characteristics may be changed.

<sup>2</sup> Stresses beyond those listed under absolute maximum ratings may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated under recommended operating conditions is not implied. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.


FB propagation delay to output high	$T_{FBDH}$	Falling edge of VFB from 0.25V to 0V to $V_{SW}$ rising edge		100		ns
FB propagation delay to output low	$T_{FBDL}$	Rising edge of VFB from 0V to 0.25V to $V_{SW}$ falling edge		100		ns
Thermal shutdown		Trigger thermal shutdown		150		°C
		Hysteresis		20		°C

## ■ TYPICAL OPERATING CHARACTERISTICS


**Quiescent Current vs Input Voltage**




**Shutdown Current vs Input Voltage**




**I<sub>out</sub> vs  $\eta$**



**Line Regulation**



**LDOO vs LDOI**





## ■ APPLICATION INFORMATION

### 1 Hysteresis Current Control with Adaptive Threshold Adjustment

The HT7887 operates in a hysteretic voltage-control mode to regulate the output voltage. FB is connected to the tap of a resistor divider, which determines the output voltage. The power MOSFET is turned on when the FB voltage ( $V_{FB}$ ) drops to 185mV and remains on until  $V_{FB}$  rises to 215mV. The power MOSFET is turned off when  $V_{FB}$  rises to 215mV and remains off until  $V_{FB}$  falls to 185mV. The two thresholds of 215mV and 185mV are adjusted adaptively to compensate for all the circuit delays, so the output voltage is regulated with an average 200mV value at FB.

### 2 Enable (EN) Control

The HT7887 has a dedicated enable control pin (EN) with positive logic. Its falling threshold is 1.3V, and its rising threshold is 1.7V.

When floating, EN is pulled up to about 2.5V by an internal 2 $\mu$ A current source, so it is enabled. A current over 2 $\mu$ A is needed to pull EN down.

### 3 Floating Driver and Bootstrap Charging

The floating power MOSFET driver is powered by an external bootstrap capacitor. This floating driver has its own under-voltage lockout (UVLO) protection. The UVLO rising threshold is 2.2V with a hysteresis of 150mV.

The bootstrap capacitor is charged and regulated to about 5V by the dedicated internal bootstrap regulator.

### 4 Under-Voltage Lockout (UVLO)

Under-voltage lockout (UVLO) is implemented to protect the chip from operating at an insufficient supply voltage. The UVLO rising threshold is about 4.7V, while its falling threshold is a consistent 4.4V.

### 5 LDO

The HT7887 integrated a 150mA LDO that can provide a 3.3V power supply. The input supply voltage of the LDO is LDO1, and the output voltage of the LDO is LDOO. Only when the LDO1 voltage is dropped below 3V can the LDO be disabled.

The LDO1 can be connected to VOUT or external power supply. If the LDO1 is connected to VOUT, make sure that the VOUT is set in the recommended LDO1 voltage. If LDO1 is connected to an external power supply, the LDO can work singly even if the buck is disabled.

Filtering capacitors should be placed as close to the device as possible for both LDO1 and LDOO.

### 6 Thermal Shutdown

Thermal shutdown is implemented to prevent the chip from operating at exceedingly high temperatures. When the silicon die temperature is higher than its upper threshold, the entire chip shuts down. When the temperature is lower than its lower threshold, the chip is enabled again.

HT7887 在滞后电压控制模式下工作，以调节输出电压。FB 连接到电阻分压器的中间，电阻分压器决定输出电压。当 FB 电压 ( $V_{FB}$ ) 降至 185mV 时，功率 MOSFET 开启，并保持开启状态，直到  $V_{FB}$  升至 215mV。当  $V_{FB}$  上升到 215mV 时，功率 MOSFET 关闭，并保持关闭状态，直到  $V_{FB}$  下降到 185mV。215mV 和 185mV 的两个阈值自适应调整，以补偿所有电路延迟，因此输出电压在 FB 处以平均 200mV 值调节。

HT7887 的 EN 脚高电平有效，控制芯片使能。其下降阈值为 1.3V，上升阈值为 1.7V。

悬空时，EN 被内部 2 $\mu$ A 电流源拉高至约 2.5V，芯片使能。需要超过 2 $\mu$ A 的电流才能将 EN 下拉。

功率 MOSFET 驱动由外部自举电容器供电。该功率管有其自身的欠压锁定 (UVLO) 保护。UVLO 上升阈值为 2.2V，磁滞 150mV。

内部自举调节器通过外部自举电容充电调节至约 5V。

欠压锁定 (UVLO) 功能可避免芯片工作在电源电压不足的条件。UVLO 上升阈值约为 4.7V，下降阈值为 4.4V。

HT7887 内置了一个 150mA LDO，其可输出 3.3V 电压。该 LDO 的输入是 LDO1，输出是 LDOO。只有当 LDO1 的电压低于 3V 时，LDO 才会关闭。

LDO1 可连接至 VOUT，也可接到外部供电。接到 VOUT 时，注意将 VOUT 设置在 LDO1 推荐电压范围内；若 LDO1 接到外部电压，LDO 可独立工作，即使降压处于关闭状态。

LDO1 和 LDOO 均需要连接滤波电容，以确保稳定性。

过热关断保护是为了防止芯片在极高的温度下工作。当芯片温度高于其上限阈值时，整个芯片关闭。当温度低于其下限阈值时，芯片再次启用。

## 7 Output Short Protection

For the buck, the output voltage is well-regulated when  $V_{FB}$  is around 200mV. If the output is pulled low in over-current protection (OCP) or is shorted to GND directly,  $V_{FB}$  is low, even though the power MOSFET is turned on. The HT7887 regards the low  $V_{FB}$  as a failure. The power MOSFET shuts off if the failure time is longer than 10 $\mu$ s. The HT7887 attempts operation again after a delay of about 300 $\mu$ s.

The power MOSFET current is also accurately sensed via a current sense MOSFET. If the current is over the current limit, the IC is shut down. This offers extra protection under output-short conditions.

For the LDO, when the output current of LDOO is higher than LDO current limit or the LDOO is short to GND, the output short protection is triggered and the output current is clamped at 80mA to avoid thermal damage.

## 8 Setting the Output Voltage

The output voltage ( $V_{OUT}$ ) is set by a resistor divider (R1 and R2) (see the Typical Application on page 2). The resistor divider can be determined with following Equation.

$$R1 = \frac{V_{OUT} - V_{FB}}{V_{FB}} \times R2$$

Where  $V_{FB}$  is 0.2V, typically.

## 9 Output Capacitor and Frequency Setting

The output capacitor ( $C_{OUT}$ ) is necessary for achieving a smooth output voltage. The ESR of the capacitor should be sufficiently large compared to the capacitance; otherwise, the system may behave in an unexpected way, and the current ripple may be very high.  $V_{FB}$  changes from 185mV to 215mV when the power MOSFET switches on. To charge the capacitor and generate 215mV at FB, the system needs ESR and some inductor current. For example, for a 5V  $V_{OUT}$ , if the forward capacitor is 0.1 $\mu$ F, the suggested ESR range of the output capacitor is 100m $\Omega$  to 250m $\Omega$ . Tantalum or aluminum electrolytic capacitors with a small ceramic capacitor are recommended.

A forward capacitor across R1 is recommended when the output capacitor is tantalum or aluminum electrolytic, which can set the desired frequency if the output capacitor and ESR cannot be changed. The forward capacitor can reduce the output voltage ripple.

In some application, simply a forward capacitor may not get proper frequency, then we can add a forward resistor in series with the forward capacitor or even more add a ceramic on the output.

对于芯片降压部分, 当  $V_{FB}$  在 200mV 左右时, 输出电压被稳定调节。如果输出在过电流保护 (OCP) 中拉低或直接对 GND 短路, 则  $V_{FB}$  低, 即使功率 MOSFET 开启。HT7887 将低  $V_{FB}$  视为故障。如果故障时间超过 10 $\mu$ s, 功率 MOSFET 将关闭。HT7887 在大约 300 $\mu$ s 的延迟后再次尝试工作。

功率 MOSFET 电流通过电流检测 MOSFET 精确检测。如果电流超过电流限制, IC 将关闭。这在输出短路条件下提供了额外的保护。

对于 LDO 部分, 当 LDOO 引脚的输出电流高于电流限制阈值或 LDOO 对 GND 短路时, 将触发短路保护, 输出电流将被箝位至约 80mA, 以防止温度过高造成芯片损坏。

输出电压 ( $V_{OUT}$ ) 由电阻分压器 (R1 和 R2) 设置 (参见第 2 页的典型应用)。可以使用以下公式确定电阻。

$$R1 = \frac{V_{OUT} - V_{FB}}{V_{FB}} \times R2$$

其中,  $V_{FB}$  的典型值为 0.2V。

输出电容 ( $C_{OUT}$ ) 是实现平滑输出电压所必需的。与电容值相比, 电容的 ESR 应足够大; 否则, 系统可能会以意外的方式运行, 并且电流纹波可能非常高。当功率 MOSFET 打开时,  $V_{FB}$  从 185mV 变为 215mV。为了给电容器充电并在 FB 处产生 215mV, 系统需要 ESR 和一些电感电流。例如, 对于 5V  $V_{OUT}$ , 如果正向电容器为 0.1 $\mu$ F, 建议的输出电容器 ESR 范围为 100m $\Omega$  至 250m $\Omega$ 。建议使用小型陶瓷电容并联钽或铝电解电容。

当输出电容为钽或铝电解电容时, 建议在 R1 上并联正向电容器, 其在不能改变输出电容和 ESR 时可设置所需开关频率。该正向电容可以降低输出电压纹波。

在某些应用中, 单一的正向电容器可能无法获得合适的开关频率, 则可以添加一个正向电阻与正向电容器串联, 或甚至在输出端添加一个陶瓷电容。

## 10 Selecting the Inductor

The inductor (L) is required to convert the switching voltage to a smooth current to the load. Although the output current is low, it is recommended that the inductor current be continuous in each switching period to prevent reaching the current limit. Calculate the inductor value with the following Equation.

$$L = \frac{(V_{IN} - V_{OUT}) \times V_{OUT}}{F_{SW} \times I_{OUT} \times V_{IN} \times K}$$

Where K is a coefficient of about 0.15 ~ 0.85.

## 11 Output Rectifier Diode

The output rectifier diode supplies current to the inductor when the high-side switch is off. To reduce losses due to the diode forward voltage and recovery times, use a Schottky diode.

The average current through the diode can be approximated with the following Equation:

$$I_D = I_{OUT} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right)$$

Choose a diode with a maximum reverse voltage rating greater than the maximum input voltage and a current rating is greater than the average diode current.

## 12 Input Capacitor (C<sub>IN</sub>)

The input current to the step-down converter is discontinuous and therefore requires a capacitor to supply AC current to the step-down converter while maintaining the DC input voltage. Use low ESR capacitors for the best performance, especially under high switching frequency applications.

The RMS current through the input capacitor can be calculated with the following Equation:

$$I_{IN\_AC} = I_{OUT} \times \sqrt{\frac{V_{OUT}}{V_{IN}} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right)}$$

With low ESR capacitors, the input voltage ripple can be estimated with the following Equation.

$$\Delta V_{IN} = \frac{I_{OUT} \times V_{OUT}}{F_{SW} \times C_{IN} \times V_{IN}} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right)$$

Choose an input capacitor with enough RMS current rating and enough capacitance for small input voltage ripples.

When electrolytic or tantalum capacitors are applied, a small, high-quality ceramic capacitor (i.e.: 0.1μF) should be placed as close to the IC as possible.

电感器 (L) 需要将开关电压转换为平滑的负载电流。虽然输出电流较低, 但建议在每个开关周期内电感电流保持连续, 以防止达到电流限制。可使用以下公式计算电感器值。

$$L = \frac{(V_{IN} - V_{OUT}) \times V_{OUT}}{F_{SW} \times I_{OUT} \times V_{IN} \times K}$$

其中系数 K 约为 0.15~0.85。

当高压侧开关断开时, 输出整流二极管向电感器提供电流。为了减少二极管正向电压和恢复时间造成的损耗, 请使用肖特基二极管。

通过二极管的平均电流可通过以下公式计算:

$$I_D = I_{OUT} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right)$$

选择最大反向电压额定值大于最大输入电压且额定电流大于平均二极管电流的二极管。

降压转换器的输入电流是不连续的, 因此需要一个电容向降压转换器提供交流电流, 同时保持直流输入电压。使用低 ESR 电容以获得最佳性能, 尤其是在高开关频率应用下。

通过输入电容的 RMS 电流可通过以下公式计算。

$$I_{IN\_AC} = I_{OUT} \times \sqrt{\frac{V_{OUT}}{V_{IN}} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right)}$$

对于低 ESR 电容, 输入电压纹波可通过以下方程式估算

$$\Delta V_{IN} = \frac{I_{OUT} \times V_{OUT}}{F_{SW} \times C_{IN} \times V_{IN}} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right)$$

选择一个具有足够的 RMS 电流额定值和足够容值的电容作为输入电容, 以实现较小的输入电压纹波。

当使用电解电容或钽电容时, 应将小型优质陶瓷电容 (即: 0.1 μF) 放置在尽可能靠近 IC 的位置。

### 13 PCB Layout Guidelines

Efficient PCB layout is critical for stable operation. For best results, refer to Figure 1 and follow the guidelines below.

(1) Place the input decoupling capacitor, output rectifier diode, and the HT7887 (VIN, SW, and PGND) as close to each other as possible.

(2) Keep the power traces very short and fairly wide, especially for the SW node.

This can help greatly reduce voltage spikes on the SW node and lower the EMI noise level.

(3) Run the feedback trace as far from the inductor and noisy power traces (like the SW node) as possible.

(4) Place thermal vias with 15mil barrel diameter and 40mil pitch (distance between the centers) under the exposed pad to improve thermal conduction.

有效的 PCB 布局对于稳定运行至关重要。要获得最佳结果，请参考图 1 并遵循以下指南。

(1) 将输入电容器、二极管和 HT7887 (VIN、SW 和 PGND) 尽可能靠近。

(2) 保持电源轨迹非常短且相当宽，特别是对于 SW 节点。


这有助于大大降低 SW 节点上的电压尖峰，并降低 EMI 噪声水平。

(3) FB 走线尽可能远离电感和功率走线（如 SW 节点）。

(4) 将直径为 15mil、间距为 40mil（中心之间的距离）的热通孔放置在裸露的焊盘下方，以改善热传导。

**■ PACKAGE OUTLINE**

SPE (ESOP8)



Symbol	Dimensions in Millimeters Choice 1 (B)		Dimensions in Millimeters Choice 2 (T)	
	Min.	Max.	Min.	Max
A	1.3	1.7	1.35	1.55
A1	0.00	0.10	0.00	0.10
D	4.70	5.10	4.70	5.10
E	3.80	4.00	3.80	4.00
E1	5.80	6.20	5.80	6.20
D1	3.05	3.25	3.3 REF	
E2	2.16	2.36	2.4 REF	
b	0.33	0.51	0.30	0.45
c	0.17	0.25	0.18	0.22
e	1.27TYP.		1.27TYP.	
L	0.40	1.27	0.40	0.80
θ	0°	8°	0°	8°

**IMPORTANT NOTICE****注意**

Heroic Electronic Technology (Jiaxing) Co., Ltd (HT) reserves the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any products or services. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

禾润电子科技（嘉兴）股份有限公司（以下简称HT）保留对产品、服务、文档的任何修改、更正、提高、改善和其他改变，或停止提供任何产品和服务的权利。客户在下单和生产前应确保所得到的信息是最新、最完整的。

HT assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using HT components.

HT对相关应用的说明和协助以及客户产品的板级设计不承担任何责任。

HT products are not authorized for use in safety-critical applications (such as life support devices or systems) where a failure of the HT product would reasonably be expected to affect the safety or effectiveness of that devices or systems.

HT的产品并未授权用于诸如生命维持设备等安全性极高的应用中。

The information included herein is believed to be accurate and reliable. However, HT assumes no responsibility for its use; nor for any infringement of patents or other rights of third parties which may result from its use.

本文中的相关信息是精确和可靠的，但HT并不对其负责，也不对任何可能的专利和第三方权利的侵害负责。

Following are URLs and contacts where you can obtain information or supports on any HT products and application solutions:

下面是可以联系到我公司的相关链接和联系方式：

**禾润电子科技（嘉兴）股份有限公司**  
**Heroic Electronic Technology (Jiaxing) Co., Ltd.**

地址： 浙江省嘉兴市凌公塘路3339号JRC大厦A座三层

Add: A 3rd floor, JRC Building, No. 3339, LingGongTang Road, Jiaxing, Zhejiang Province

Sales: 0573-82585539, sales@heroic.com.cn

Support: 0573-82586151, support@heroic.com.cn

Fax: 0573-82585078

Website: www.heroic.com.cn; wap.heroic.com.cn

Wechat MP: HEROIC\_JX

请及时关注禾润官方微信公众号，随时获取最新产品信息和技术资料！





